

ASUS AI TouchMedia Lyn Guide

DA4243 / September 2008

Oversigt

AI TouchMedia

ASUS AI TouchMedia er et komplet multimedie-center, som øger fornøjelsen ved musik, billeder, videoer og film.

Du kan kombinere tastaturets pil-knapper og multimedie berøringspanelet til navigation rundt på ASUS AI TouchMedia. Det er nemt for dig at vælge og rulle igennem de følgende valgmuligheder.

Musik

Du kan lytte til musikfiler (in .mp3, .wav og .wma formater) med visualiseringer og skabe dine egne favorit-afspilningslister (i .wpl formatet) og i den ønskede rækkefølge.

Billeder

Du kan se dine billeder (i JPG, PNG og BMP formater) i et dias-show og ændre dine billeder med AI TouchMedia. Vælg **Browse By (Gennemse efter)** knappen for at sortere billederne efter mappe, dato (dato, hvor taget, eller ændringsdato) eller efter klassificering.

Videoer

AI TouchMedia understøtter videoer i MPEG- 1/2, WMV, WMV-HD, DVRMS og AVI formater. Vælg **Browse By (Gennemse efter)** knappen for at sortere videoerne efter mappe, dato (dato, hvor taget, eller ændringsdato) eller efter klassificering.

Indstillinger


Vælg **Settings (Indstillinger)** på hovedpanelet for at konfigurere indstillingerne for AI TouchMedia.

Film

Med AI TouchMedia kan du afspille dvd- og Blu-ray diske (på Blu-ray optisk drev modeller).


Brug af multimedia berøringspanel

Multimedia berøringspanelet hjælper med at styre ASUS AI TouchMedia, når der lyttes til musik eller ses film.



Brug af AI TouchMedia

1. Double-click the **AI TouchMedia** shortcut on the desktop to launch AI TouchMedia.



2. Brug pilknapperne til at rulle og vælg en funktion i **Music (Musik)**, **Photos (Billeder)**, **Videos (Videoer)** og **Movies (Film)** eller vælg **Settings (Indstillinger)** for at konfigurere multimedie-indstillingerne.




Du kan aktivere **Music (Musik)** og **Movies (Film)** funktionerne ved at springe trin 1 over og trykke direkte på de tilsvarende knapper på kontrolpanelet.

3. Når du har valgt en funktion, skal du åbne underniveaueet med den højre pilknep og begynde at bruge funktionerne.
4. Brug den venstre pilknep eller <ESC> til at vende tilbage til det foregående niveau, hvis du ønsker at bruge andre funktioner.


Lytning til musik og visning af film

Sådan bruger du AI TouchMedia til at lytte til musik eller se film.

1. Tryk på **Music (Musik)/Movies (Film)** for at aktivere funktionen.




Aktiver musik direkte




Aktiver film direkte

2. Brug styrefeltet til at afspille/pausere, tilbagespole, køre hurtigt fremad eller til at springe til næste/foregående spor.



Kontrol AI TouchMedia

3. Brug lydstyrkebjælken til om ønsket at indstille højttalerens lydstyrke.



Kør op og ned

Copyright Information

No part of this manual, including the products and software described in it, may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form or by any means, except documentation kept by the purchaser for backup purposes, without the express written permission of ASUSTeK COMPUTER INC. ("ASUS").

ASUS PROVIDES THIS MANUAL "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT SHALL ASUS, ITS DIRECTORS, OFFICERS, EMPLOYEES OR AGENTS BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES (INCLUDING DAMAGES FOR LOSS OF PROFITS, LOSS OF BUSINESS, LOSS OF USE OR DATA, INTERRUPTION OF BUSINESS AND THE LIKE), EVEN IF ASUS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES ARISING FROM ANY DEFECT OR ERROR IN THIS MANUAL OR PRODUCT.

Products and corporate names appearing in this manual may or may not be registered trademarks or copyrights of their respective companies, and are used only for identification or explanation and to the owners' benefit, without intent to infringe.

SPECIFICATIONS AND INFORMATION CONTAINED IN THIS MANUAL ARE FURNISHED FOR INFORMATIONAL USE ONLY, AND ARE SUBJECT TO CHANGE AT ANY TIME WITHOUT NOTICE, AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY ASUS. ASUS ASSUMES NO RESPONSIBILITY OR LIABILITY FOR ANY ERRORS OR INACCURACIES THAT MAY APPEAR IN THIS MANUAL, INCLUDING THE PRODUCTS AND SOFTWARE DESCRIBED IN IT.

Copyright © 2008 ASUSTeK COMPUTER INC. All Rights Reserved.

Limitation of Liability

Circumstances may arise where because of a default on ASUS' part or other liability, you are entitled to recover damages from ASUS. In each such instance, regardless of the basis on which you are entitled to claim damages from ASUS, ASUS is liable for no more than damages for bodily injury (including death) and damage to real property and tangible personal property; or any other actual and direct damages resulted from omission or failure of performing legal duties under this Warranty Statement, up to the listed contract price of each product.

ASUS will only be responsible for or indemnify you for loss, damages or claims based in contract, tort or infringement under this Warranty Statement.

This limit also applies to ASUS' suppliers and its reseller. It is the maximum for which ASUS, its suppliers, and your reseller are collectively responsible.

UNDER NO CIRCUMSTANCES IS ASUS LIABLE FOR ANY OF THE FOLLOWING: (1) THIRD-PARTY CLAIMS AGAINST YOU FOR DAMAGES; (2) LOSS OF, OR DAMAGE TO, YOUR RECORDS OR DATA; OR (3) SPECIAL, INCIDENTAL, OR INDIRECT DAMAGES OR FOR ANY ECONOMIC CONSEQUENTIAL DAMAGES (INCLUDING LOST PROFITS OR SAVINGS), EVEN IF ASUS, ITS SUPPLIERS OR YOUR RESELLER IS INFORMED OF THEIR POSSIBILITY.

Service and Support

Visit our multi-language web site at <http://support.asus.com>