

ASUS AI TouchMedia

Hurtigstartsveiledning

NW4243 / September 2008

Oversikt

AI TouchMedia

ASUS AI TouchMedia er et komplett multimediasenter som forbedrer opplevelsen av fotoene, videoene, musikken og filmene dine.

Du kan kombinere piltastene på tastaturet og multimediasberøringspanelet for å navigere rundt i ASUS AI TouchMedia. Det er praktisk for deg å velge og bla i følgende alternativer.

Musikk

Du kan lytte til musikkfiler (i .mp3, .wav og .wma-formater) med visualisering og opprett favorittspillelistene (i .wpl-formatet) i foretrukket rekkefølge.

Bilder

Du kan se bildene dine (i JPG-, PNG- og BMP-formater) i en lysbildevisning, og tilpasse bildene med AI TouchMedia. Velg **Browse By (Søk etter)**-knappen for å sortere bildene dine etter mappe, dato (dato for siste opptak eller siste tilpasning) eller rangering.

Videoer

AI TouchMedia støtter videoer i MPEG- 1/2, WMV, WMV-HD, DVRMS og AVI-formater. Velg **Browse By (Søk etter)**-knappen for å sortere videoene dine etter mappe, dato (dato for siste opptak eller siste tilpasning) eller rangering.

Innstillinger


Velg **Settings (Innstillinger)** på hovedpanelet for å konfigurere innstillingene for AI TouchMedia.

Filmer

Du kan spille DVD og Blu-ray-disker (på Blu-ray optiske enheter) med AI TouchMedia.


Bruke multimedieberøringspanelet

Multimedieberøringspanelet hjelper deg kontrollere ASUS AI TouchMedia når du lytter til musikk eller ser på en film.



Bruke AI TouchMedia

1. Dobbeltklikk på AI TouchMedia-snarveien på skrivebordet for å starte AI TouchMedia.



2. Bruk piltastene for å bla og velge en funksjon fra **Music (Musikk)**, **Photos (Fotoer)**, **Videos (Videoer)** og **Movies (Filmer)** eller velg **Settings (Innstillinger)** for å konfigurere multimedieinnstillinger.




For å aktivere **Music (Musikk)** eller **Movies (Filmer)**-funksjoner, kan du hoppe over trinn 1 og trykke på korresponderende knapper direkte på kontrollpanelet.

3. Etter at du velger en funksjon, bruk høyre piltast for å gå inn i undernivået og begynn å bruke funksjonene.
4. Bruk venstre piltast eller <ESC>-tasten for å gå tilbake til forrige nivå hvis du vil velge og bruke andre funksjoner.


Lytte til musikk eller se på filmer

For å bruke AI TouchMedia til å lytte til musikk eller se på filmer

1. Trykk på Music (Musikk) /Movies (Filmer)-knappen for å aktivere funksjonen.




Aktiver musikk direkte




Aktiver filmer direkte

2. Bruk kontrollområdet til å spille av/pause, spole tilbake, spole fremover eller hoppe til neste/forrige spor.



Kontroller AI TouchMedia

3. Bruk Justeringslinjen for volum for å tilpasse lydnivået.



Skv opp eller ned

Copyright Information

No part of this manual, including the products and software described in it, may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form or by any means, except documentation kept by the purchaser for backup purposes, without the express written permission of ASUSTeK COMPUTER INC. ("ASUS").

ASUS PROVIDES THIS MANUAL "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT SHALL ASUS, ITS DIRECTORS, OFFICERS, EMPLOYEES OR AGENTS BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES (INCLUDING DAMAGES FOR LOSS OF PROFITS, LOSS OF BUSINESS, LOSS OF USE OR DATA, INTERRUPTION OF BUSINESS AND THE LIKE), EVEN IF ASUS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES ARISING FROM ANY DEFECT OR ERROR IN THIS MANUAL OR PRODUCT.

Products and corporate names appearing in this manual may or may not be registered trademarks or copyrights of their respective companies, and are used only for identification or explanation and to the owners' benefit, without intent to infringe.

SPECIFICATIONS AND INFORMATION CONTAINED IN THIS MANUAL ARE FURNISHED FOR INFORMATIONAL USE ONLY, AND ARE SUBJECT TO CHANGE AT ANY TIME WITHOUT NOTICE, AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY ASUS. ASUS ASSUMES NO RESPONSIBILITY OR LIABILITY FOR ANY ERRORS OR INACCURACIES THAT MAY APPEAR IN THIS MANUAL, INCLUDING THE PRODUCTS AND SOFTWARE DESCRIBED IN IT.

Copyright © 2008 ASUSTeK COMPUTER INC. All Rights Reserved.

Limitation of Liability

Circumstances may arise where because of a default on ASUS' part or other liability, you are entitled to recover damages from ASUS. In each such instance, regardless of the basis on which you are entitled to claim damages from ASUS, ASUS is liable for no more than damages for bodily injury (including death) and damage to real property and tangible personal property; or any other actual and direct damages resulted from omission or failure of performing legal duties under this Warranty Statement, up to the listed contract price of each product.

ASUS will only be responsible for or indemnify you for loss, damages or claims based in contract, tort or infringement under this Warranty Statement.

This limit also applies to ASUS' suppliers and its reseller. It is the maximum for which ASUS, its suppliers, and your reseller are collectively responsible.

UNDER NO CIRCUMSTANCES IS ASUS LIABLE FOR ANY OF THE FOLLOWING: (1) THIRD-PARTY CLAIMS AGAINST YOU FOR DAMAGES; (2) LOSS OF, OR DAMAGE TO, YOUR RECORDS OR DATA; OR (3) SPECIAL, INCIDENTAL, OR INDIRECT DAMAGES OR FOR ANY ECONOMIC CONSEQUENTIAL DAMAGES (INCLUDING LOST PROFITS OR SAVINGS), EVEN IF ASUS, ITS SUPPLIERS OR YOUR RESELLER IS INFORMED OF THEIR POSSIBILITY.

Service and Support

Visit our multi-language web site at <http://support.asus.com>