

E2071  
First Edition V1  
May 2005

**ASUS<sup>®</sup>**

# **TV Tuner Card**

*My Cinema-P7131D*

*My Cinema-P7131*

# 1. Welcome!


Thank you for buying an ASUS® TV Tuner Card!

The ASUS® TV Tuner Card integrates several multimedia functions that allow you to transform your PC into the ultimate entertainment center. With the ASUS® TV Tuner Card, you can watch and record live TV, capture and play back videos, make VCD/DVD movies, listen to MP3 music, tune in to your favorite FM station, and view photos on your PC.


Bundled with the ASUS® remote controller and the CyberLink PowerCinema application, the ASUS® TV Tuner Card offers performance, functionality, and enjoyment.

# 2. Card layout

## My Cinema P7131D Digital/Analog TV card




## My Cinema P7131 Analog TV card



Drawings are for reference only. The actual card layout may vary.

### 3. Connecting cables and devices




## 4. Remote controller

The ASUS remote controller allows you to operate the ASUS TV Tuner Card from a distance. Use the remote controller to navigate through the CyberLink My Cinema windows.






















### Remote controller specifications

<b>Operating range</b>	5 meters (max)
<b>Power source</b>	3 V (2 x "AAA" batteries)
<b>Receiver</b>	Infrared receiver (supplied)








### 4.1 Layout



## 4.2 Key table

Button	Mode					
	TV	FM	DVD	VIDEO	PHOTO	MUSIC
	TV mode	-	-	-	-	-
	-	Radio mode	-	-	-	-
	-	-	DVD mode	-	-	-
	-	-	-	Video mode	-	-
	-	-	-	-	Photo mode	-
	-	-	-	-	-	Music mode
	Back to main menu	Back to main menu	Back to main menu	Back to main menu	Back to main menu	Back to main menu
	-	-	DVD menu	-	-	-
	Mute	Mute	Mute	Mute	Mute	Mute
	Full screen	Full screen	Full screen	Full screen	Full screen	Full screen
	Back to previous channel	-	-	-	-	-
	Back to previous page	Back to previous page	Back to previous page	Back to previous page	Back to previous page	Back to previous page
	Channel up/down	Search forward/backward	Next/previous chapter	-	-	-
	Volume up/down	Volume up/down	Volume up/down	Volume up/down	Volume up/down	Volume up/down
	0 ~ 9	0 ~ 9	0 ~ 9	-	-	-
	Enter	Enter	Enter	Enter	Enter	Enter
	Up	Up	Up	Up	Up	Up
	Down	Down	Down	Down	Down	Down
	Left	Left	Left	Left	Left	Left
	Right	Right	Right	Right	Right	Right
	Record	Record	Record	Record	Record	Record

(Continued on the next page)


Button	Mode					
	TV	FM	DVD	VIDEO	PHOTO	MUSIC
	Close app	Close app	Close app	Close app	Close app	Close app
	Stop	Stop	Stop	Stop	Stop	Stop
	Previous chapter	Previous chapter	Previous chapter	Previous chapter	Previous chapter	Previous chapter
	Next chapter	Next chapter	Next chapter	Next chapter	Next chapter	Next chapter
	Rewind	Rewind	Rewind	Rewind	Rewind	Rewind
	Forward	Forward	Forward	Forward	Forward	Forward
	Play/pause	Play/pause	Play/pause	Play/pause	Play/pause	Play/pause

## 5. Software information

This section gives an overview of the CyberLink PowerCinema application that comes with the ASUS® TV Tuner Card. This application allows you to watch TV and DVDs, listen to FM radio or music CDs, or browse photos stored in your computer. Use the mouse or the remote controller to navigate through the user interface. For details on the remote controller, see pages 1-4 and 1-5.

### 5.1 Cyberlink PowerCinema



The main menu has six multimedia functions. Select the function you want by pressing the up/down arrow key on the remote controller or by using the mouse. To launch the function, press  on the remote controller or click the mouse.

For more information on the PowerCinema application, click [here](#).

## TV

- Record live TV
- Preview multiple channels
- Schedule recordings
- Capture still images



## Movies

- Watch DVD/VCD movies
- Capture still images



## Videos

- Organize recorded videos
- Display TV/DVD recordings
- Capture still images
- Play slideshows with music



## Music

- Enjoy MP3 music
- Record and play back music
- Organize your playlist



## Pictures

- Organize your photos
- Display captured images from TV/DVD/VCD
- Print photos



## Radio

- Listen to your favorite FM radio programs
- Record programs



## Create and share DVD/VCD videos

The CyberLink PowerCinema application makes creating and sharing videos fast and and easy.

### Burn videos in DVD or VCD

For more information, click [here](#).






## Author videos

For more information, click [here](#).



## Edit and burn videos in DVD or VCD

For more information, click [here](#).



## 5.2 VideoSecurity Online

VideoSecurity Online is a powerful monitoring and motion-detecting software. With video capture devices such as CCD, V8, digital Hi-8 and others, you can use VideoSecurity Online to:

- find intruders
- monitor your environment
- detect changes in a specified location
- know in advance who your visitors are

Upon detection of any variation, whether it is an error or not, VideoSecurity Online will do the following:

- save the date/time information on when the condition started, and when to release tracing to a database file. (watchdog.mdb)
- capture the condition detected and save it into a bitmap file with reference to an image that represents the normal situation before VideoSecurity Online started detecting the variation. You may view any image processing software to view, modify, or distribute the image.



---

This database file is saved in the Programs folder.

---

VideoSecurity Online also lets the user choose from four options on how to handle the variation or unusual condition detected.

For more information, click [here](#).