HDMI
HIGH-DEFINITION MULTIMEDIA INTERFACE

ASUSPRO Ultra Docking Station

User Guide

15060-43800000

IN SEARCH OF INCREDIBLE

BC

Hardware features

Top View

Power adapter indicator

USB connector with docking pins   Docking hooks   Docking stand

Power button with LED indicator

Switch

Bottom View

12" Notebook PC

14" and 15" Notebook PC

Rubber feet lock

Model switch

Adjustable rubber feet

Rear View

USB 3.0 with USB Charger+   USB 3.0 ports   Power input port

LAN port

VGA port   Microphone output jack port

Displayport   Headphone output jack port

HDMI port

Left Side   Right Side

Key lock   Kensington® Security slot

Safety notices for your ASUSPRO Ultra Docking Station

WARNING!
The bottom of the ASUSPRO Ultra Docking Station can get warm to hot while in use or while charging the battery pack. When working on your ASUSPRO Ultra Docking Station, do not place it on surfaces that can block the vents.

CAUTION!
• This ASUSPRO Ultra Docking Station should only be used in environments with ambient temperatures between 5℃ (41°F) and 35℃ (95°F).

• Refer to the rating label on the bottom of your ASUSPRO Ultra Docking Station and ensure that your power adapter complies with this rating.

• The power adapter may become warm to hot while in use. Do not cover the adapter and keep it away from your body while it is connected to a power source.

Docking your Notebook PC

A

B

C

Using the docking stand

IMPORTANT! Ensure that nothing is placed beneath the docking stand when the Notebook PC is angled to a 90-degree position.

Connecting to a power outlet

IMPORTANT!
• The socket outlet must be near to the unit and easily accessible.
• Locate the input/output rating label on your ASUSPRO Ultra Docking Station and ensure that it matches the input/output rating information on your power adapter.
• Power adapter information:
  - Input voltage: 100-240Vac
  - Input frequency: 50-60Hz
  - Rating output current: 3.42A (65W)
  - Rating output voltage: 19V

Connecting to a wired external display and input devices

NOTE: When connecting wireless devices, refer to your wireless device's user guide for detailed instructions when using it with a docking station.

Copyright Information

You acknowledge that all rights of this Manual remain with ASUS. Any and all rights, including without limitation, in the Manual or website, are and shall remain the exclusive property of ASUS and/or its licensors. Nothing in this Manual intends to transfer any such rights, or to vest any such rights to you.

ASUS PROVIDES THIS MANUAL "AS IS" WITHOUT WARRANTY OF ANY KIND. SPECIFICATIONS AND INFORMATION CONTAINED IN THIS MANUAL ARE FURNISHED FOR INFORMATIONAL USE ONLY, AND ARE SUBJECT TO CHANGE AT ANY TIME WITHOUT NOTICE, AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY ASUS.

Limitation of Liability

Circumstances may arise where because of a default on ASUS' part or other liability, you are entitled to recover damages from ASUS. In each such instance, regardless of the basis on which you are entitled to claim damages from ASUS, ASUS is liable for no more than damages for bodily injury (including death) and damage to real property and tangible personal property; or any other actual and direct damages resulted from omission or failure of performing legal duties under this Warranty Statement, up to the listed contract price of each product.

ASUS will only be responsible for or indemnify you for loss, damages or claims based in contract, tort or infringement under this Warranty Statement.

This limit also applies to ASUS' suppliers and its reseller. It is the maximum for which ASUS, its suppliers, and your reseller are collectively responsible.

UNDER NO CIRCUMSTANCES IS ASUS LIABLE FOR ANY OF THE FOLLOWING: (1) THIRD-PARTY CLAIMS AGAINST YOU FOR DAMAGES; (2) LOSS OF, OR DAMAGE TO, YOUR RECORDS OR DATA; OR (3) SPECIAL, INCIDENTAL, OR INDIRECT DAMAGES OR FOR ANY ECONOMIC CONSEQUENTIAL DAMAGES (INCLUDING LOST PROFITS OR SAVINGS), EVEN IF ASUS, ITS SUPPLIERS OR YOUR RESELLER IS INFORMED OF THEIR POSSIBILITY.

Service and Support

Visit our multi-language web site at **http://support.asus.com**

EC Declaration of Conformity