

Declaration of Conformity

We, Manufacturer/Importer
(full address)

**ASUS COMPUTER GmbH HARKORT STR. 25
40880 RATINGEN, BRD. GERMANY**

declare that the product
(description of the apparatus, system, installation to which it refers)
is in conformity with

(reference to the specification under which conformity is declared)

in accordance with 2004/108/EC-EMC Directive and 1995/5 EC-R &TTE Directive

Product name: Broad range wireless family router

Model name : RT-G32

- | | | | |
|---|---|---|---|
| <input type="checkbox"/> EN 50392 | Generic standard to demonstrate the compliance of electronic and electrical apparatus with the basic restrictions related to human exposure to electromagnetic fields (0 Hz-300GHz) | <input checked="" type="checkbox"/> EN 61000-3-2* | Disturbances in supply systems caused |
| <input type="checkbox"/> EN 50360
EN 50361 | the limitation of exposure of the general public to electromagnetic network equipment fields (0 Hz to 300 GHz) International Commission on Non-Ionizing Radiation Protection (1998), Guidelines for limiting exposure in time-varying electric, magnetic ,and electromagnetic fields | <input checked="" type="checkbox"/> EN 61000-3-3* | Disturbances in supply systems caused |
| <input type="checkbox"/> EN50081-1 | Generic emission standard Part 1: Residual, commercial and light industry | <input type="checkbox"/> EN 301893 | Broadband Radio Access Networks (BRAN); 5 GHz high performance RLAN; Harmonized EN covering essential requirements of article 3.2 of the R&TTE Directive |
| <input type="checkbox"/> EN50082-2 | Generic immunity standard Part 2: Industrial environment | <input checked="" type="checkbox"/> EN 300328 | Electromagnetic compatibility and Radio spectrum Matters (ERM); wideband transmission equipment operating in the 2.4GHz ISM band and using spread spectrum modulation techniques. Harmonized EN covering essential requirements under article 3.2 of the R&TTE Directive |
| <input type="checkbox"/> EN 55020 | Immunity from radio interference of broadcast receivers and associated equipment | <input type="checkbox"/> EN300440-1
<input type="checkbox"/> EN300440 -2 | Electromagnetic compatibility and Radio spectrum Matters (ERM);Short Range Devices (SRD);Radio equipment to be used in the 1 GHz to 40 GHz frequency range; Part 1: Technical characteristics and test methods
Part 2: Harmonized EN under article 3.2 of the R&TTE Directive |
| <input checked="" type="checkbox"/> EN 55022 | Limits and methods of measurement of radio disturbance characteristics of information technology equipment | <input type="checkbox"/> EN 301511 | Global System for Mobile communications (GSM);Harmonized EN for mobile stations in the GSM 900 and GSM 1800 bands covering essential requirements under article 3.2 of the R&TTE directive (1999/5/EC) |
| <input type="checkbox"/> EN 55024 | Information Technology equipment-Immunity characteristics-Limits and methods of measurement | <input type="checkbox"/> EN 301 908-1
<input type="checkbox"/> EN 301 908-2 | Electromagnetic compatibility and Radio spectrum Matters (ERM);Base Stations (BS), Repeaters and User Equipment (UE) for IMT-2000 Third-Generation cellular networks; Part 1: Harmonized EN for IMT-2000, introduction and common requirements, covering essential requirements of article 3.2 of the R&TTE Directive |
| <input type="checkbox"/> EN 55013 | Limits and methods of measurement of radio disturbance characteristics of broadcast receivers and associated equipment | <input checked="" type="checkbox"/> EN 301489-1
<input checked="" type="checkbox"/> EN 301489-17 | Electromagnetic compatibility and Radio spectrum Matters (ERM); Electromagnetic compatibility(EMC) standard for radio equipment and services; Part 17: Specific conditions for wideband data and HIPERLAN equipment, Part1: Common technical requirements |
| <input checked="" type="checkbox"/> EN 50385 | Product standard to demonstrate the compliances or radio Base stations and fixed terminal stations for wireless telecommunication systems with the basic restriction or the reference level to human exposure to radio frequency electromagnetic field (110MHZ-40GHZ) -General public | | |
| <input type="checkbox"/> EN 300386 | Electromagnetic compatibility and Radio spectrum Matters (ERM);Telecommunication Electromagnetic Compatibility (EMC) requirements | | |
| <input checked="" type="checkbox"/> CE marking | | | |



(EC conformity marking)

The manufacturer also declares the conformity of above mentioned product with the actual required safety standards in accordance with LVD 2006/95/EC

- | | | | |
|--|---|---|---|
| <input type="checkbox"/> EN 60065 | Safety requirements for mains operated electronic and related apparatus for household and similar general use | <input checked="" type="checkbox"/> EN 60950-1 | Safety for information technology equipment including electrical business equipment |
|--|---|---|---|

Manufacturer/Importer

(Stamp)

Date : Nov. 18 , 2008

Signature: _____

Name : Jonathan Tseng



Appendix



FCC Warning Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



CAUTION:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Prohibition of Co-location

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

Safety Information

To maintain compliance with FCC's RF exposure guidelines, this equipment should be installed and operated with minimum distance 20cm between the radiator and your body. Use on the supplied antenna.

Declaration of Conformity for R&TTE directive 1999/5/EC

Essential requirements – Article 3

Protection requirements for health and safety – Article 3.1a



Testing for electric safety according to EN 60950-1 has been conducted. These are considered relevant and sufficient.

Protection requirements for electromagnetic compatibility – Article 3.1b

Testing for electromagnetic compatibility according to EN 301 489-1 and EN 301 489-17 has been conducted. These are considered relevant and sufficient.

Effective use of the radio spectrum – Article 3.2

Testing for radio test suites according to EN 300 328- 2 has been conducted. These are considered relevant and sufficient.

CE **CE Mark Warning**



This is a Class B product, in a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.

GNU general public license

Licensing information

This product includes copyrighted third-party software licensed under the terms of the GNU General Public License. Please see The GNU General Public License for the exact terms and conditions of this license. We include a copy of the GPL with every CD shipped with our product. All future firmware updates will also be accompanied with their respective source code. Please visit our web site for updated information. Note that we do not offer direct support for the distribution.

GNU GENERAL PUBLIC LICENSE

Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc.

59 Temple Place, Suite 330, Boston, MA 02111-1307 USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Library General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.



To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

Terms & conditions for copying, distribution, & modification

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

- a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.



b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.

c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,

b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,

c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.



If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.
5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.
6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.
7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.



9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and “any later version”, you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM “AS IS” WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

DGT warning

經型式認證合格之低功率射頻電機，非經許可，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。

低功率射頻電機之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。

前項合法通信，指依電信法規定作業之無線電通信。

低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。


Index

1	English.....	1
2	Bahasa Indonesia	7
3	ไทย.....	13
4	Türkçe.....	19
5	繁體中文	25
6	简体中文	31
7	한국어.....	37



RT-G32

Wireless Router




Quick Start Guide




1. Setting up the hardware

Wired connection



Wireless connection



Note: For establishing a wireless connection, use an IEEE 802.11b/g compatible WLAN card. Refer to your wireless adapter user manual for wireless connection procedures.




Mounting options

Out of the box, the ASUS Wireless Router is designed to sit on a raised flat surface like a file cabinet or a book shelf. The unit may also be converted for mounting to a wall or ceiling.

To mount the ASUS Wireless Router:

1. Look on the underside for the two mounting hooks.
2. Mark two upper holes on a wall or on a raised flat surface.
3. Tighten two screws until only 1/4" is showing.
4. Latch the hooks of the wireless router onto the screws.



Note: Re-adjust the screws if you cannot latch the ASUS Wireless Router onto the screws or if it is too loose.

2. Accessing the wireless router

Setting an IP address for wired or wireless client

To access the ASUS Wireless Router, you must have the correct TCP/IP settings on your wired or wireless clients. Set the IP addresses of the clients within the same subnet of the ASUS Wireless Router.

Getting an IP address automatically

The ASUS Wireless Router integrates the DHCP server function, hence, your PC can automatically obtain an IP address from the ASUS Wireless Router.



Note: Before rebooting your PC, switch ON the wireless router and ensure that the router is in ready state.



3. Configuring the wireless router

If your PC connects to the router using a cable, launch a web browser and the login page of the router's web interface automatically appears.

If your PC connects to the router wirelessly, you have to select the network first.

To select the network:

1. Click **Start > Control Panel > Network Connections > Wireless Network Connection**.
2. Select a network from the **Choose a wireless network** window. Wait for it to connect.



Note: By default, the SSID of the ASUS Wireless Router is **default**. Connect to this default SSID.

3. After establishing a wireless connection, launch a web browser.

Configuring via the web interface

1. After setting up a wired or wireless connection, launch a web browser. The login page automatically appears.



Note: You may also manually key in the router's default IP address (**192.168.1.1**) to launch the router's web interface.

2. On the login page, key in the default user name (**admin**) and password (**admin**). The ASUS Wireless Router homepage appears. The homepage displays quick links to configure the main features of the wireless router.



Note: For more details on the features of the wireless router, refer to the user manual included in the support CD.




4. Using the utilities

Using EZSetup

To use EZSetup:

1. From your Windows® desktop, click **Start > All Programs > ASUS Utility > RT-G32 Wireless Router > EZSetup Wizard** to launch the EZSetup utility.
2. Follow the onscreen instructions to set up your hardware, then click **Next**.



3. Follow the succeeding onscreen instructions to complete the installation.



Note: For more details on the features of the wireless router, refer to the user manual included in the support CD.




5. WPS Quick Button Setup

When you connect a PC of wireless adapter (such as ASUS USB-N11 and PCI-G31 adapter) with WPS function, please follow the instructions below to enable the WPS Quick setup.


1. In order to use WPS, ensure that both RT-G32 wireless router and another computer's wireless software WPS function are enabled.



2. Push the WPS button at the rear panel of RT-G32 wireless router.




3. RT-G32 WLAN LED can light up and slow flash after the WPS connection established.





Router Nirkabel

RT-G32




Panduan Mulai Cepat




1. Mempersiapkan perangkat keras

Sambungan berkabel



Sambungan nirkabel



Catatan: Untuk membuat sambungan nirkabel, gunakan kartu WLAN IEEE 802.11b/g yang kompatibel. Untuk prosedur pembuatan sambungan nirkabel, lihat panduan pengguna tentang adapter nirkabel.




Pilihan pemasangan

Secara umum, ASUS RT-G32 Wireless Router dirancang untuk pemasangan pada permukaan yang rata, seperti lemari arsip atau rak buku. Unit ini juga sesuai untuk pemasangan di dinding atau langit-langit.

Untuk memasang ASUS RT-G32:

1. Cari dua pengait di bagian bawah unit.
2. Buat dua lubang di bagian atas dinding atau pada permukaan yang rata.
3. Kencangkan kedua sekrup hingga terlihat hanya 1/4 inci.
4. Pasang pengait ASUS RT-G32 ke sekrup tersebut.



Catatan: Atur ulang posisi sekrup jika ASUS Wireless Router tidak dapat dikaitkan atau jika sekrup terlalu longgar.

2. Mengakses wireless router

Menetapkan alamat IP untuk klien berkabel atau nirkabel

Agar dapat mengakses RT-G32 Wireless Router, Anda harus memiliki pengaturan TCP/IP yang tepat untuk klien berkabel atau nirkabel. Tetapkan alamat IP klien dalam subnet RT-G32 yang sama.

Mendapatkan alamat IP secara otomatis

ASUS Wireless Router terintegrasi dengan fungsi server DHCP, sehingga PC dapat memperoleh alamat IP dari ASUS Wireless Router secara otomatis.



Catatan: Sebelum menjalankan boot ulang pada PC, aktifkan wireless router, kemudian pastikan bahwa router tersebut telah berada dalam status siap.



3. Mengkonfigurasi wireless router

Jika PC tersambung ke router menggunakan kabel, buka browser Web agar halaman login antarmuka Web router ditampilkan secara otomatis.

Jika PC terhubung ke router secara nirkabel, pilih jaringan terlebih dulu.

Untuk memilih jaringan:

1. Klik **Start (Mulai) > Control Panel (Panel Kontrol) > Network Connections (Sambungan Jaringan) > Wireless Network Connection (Sambungan Jaringan Nirkabel)**.
2. Pilih jaringan dari jendela **Choose a wireless network (Pilih jaringan nirkabel)**. Tunggu hingga terhubung ke jaringan.



Catatan: Secara default, SSID RT-G32 adalah default. Sambungkan ke SSID **default** tersebut.

3. Setelah membuat sambungan nirkabel, buka browser Web.

Mengkonfigurasi melalui antarmuka Web

1. Setelah membuat sambungan berkabel atau nirkabel, buka browser Web. Halaman login akan ditampilkan secara otomatis.



Catatan: Untuk membuka antarmuka Web router, Anda juga dapat memasukkan alamat IP default router (**192.168.1.1**) tersebut secara manual.

2. Pada halaman login, masukkan sandi (**admin**) dan nama pengguna (**admin**) default. Halaman muka ASUS Wireless Router akan terbuka. Halaman muka tersebut menampilkan link cepat untuk mengkonfigurasi fitur utama pada router nirkabel.



Catatan: Untuk informasi lebih rinci tentang fitur router nirkabel, lihat panduan pengguna yang disertakan dalam CD dukungan.



4. Menggunakan utilitas

Menggunakan EZSetup

Untuk menggunakan EZSetup:

1. Dari desktop Windows®, klik **Start (Mulai) > All Programs (Semua Program) > ASUS Utility (Utilitas ASUS) > RT-G32 Wireless Router (Router Nirkabel RT-G32) > EZSetup Wizard (Panduan EZSetup)** untuk mengaktifkan utilitas EZSetup.
2. Ikuti petunjuk di layar untuk mengkonfigurasi perangkat keras, lalu klik **Next (Lanjut)**.



3. Ikuti petunjuk selanjutnya di layar untuk menyelesaikan penginstalan.



Catatan: Untuk informasi lebih rinci tentang fitur router nirkabel, lihat panduan pengguna yang terdapat dalam CD pendukung.




5. Konfigurasi Cepat Tombol WPS

Bila menyambungkan adapter nirkabel PC (misalnya, adapter ASUS USB-N11 dan PCI-G31) dengan fungsi WPS, ikuti petunjuk di bawah ini untuk mengaktifkan Konfigurasi cepat WPS.


1. Agar dapat menggunakan WPS, pastikan router nirkabel RT-G32 dan fungsi perangkat lunak WPS nirkabel pada komputer telah diaktifkan.



2. Tekan tombol WPS pada panel belakang router nirkabel RT-G32.




3. LED WLAN RT-G32 akan menyala dan berkedip lambat setelah sambungan WPS dibuat.





RT-G32

ไวร์เลส เราเตอร์




๓๕๖

คู่มือเริ่มต้นอย่างเร็ว




1. การตั้งค่าฮาร์ดแวร์

การเชื่อมต่อแบบมีสาย



การเชื่อมต่อไร้สาย



หมายเหตุ: ในการสร้างการเชื่อมต่อแบบไร้สาย ใช้ใช้การ์ด WLAN ที่คอมแพคท์กับมาตรฐาน IEEE 802.11b/g ให้อ่านคู่มือผู้ใช้อะแดปเตอร์ไร้สายของคุณ สำหรับขั้นตอนการเชื่อมต่อแบบไร้สาย




ตัวเลือกในการยึด

ASUS RT-G32 ไร้เลส เราเตอร์ ได้รับการออกแบบให้วางบนพื้นผิวเรียบ เช่นบนตู้หรือชั้นหนังสือ นอกจากนี้ คุณยังสามารถแปลงเครื่องสำหรับแขวนที่ผนังหรือเพดานได้ด้วย

ในการยึด ASUS RT-G32:

1. มองข้างใต้เครื่อง สำหรับที่เกี่ยวข้องสำหรับยึดสองอัน
2. ทำเครื่องหมายรูด้านบนสองรูบนผนังหรือบนพื้นผิวเรียบที่ยกขึ้น
3. ใช้สกรูสองตัว จนกระทั่งมีเฉพาะ 1/4" แสดงอยู่
4. ใส่ที่เกี่ยวข้องของ ASUS RT-G32 บนสกรู



หมายเหตุ: ปรับสกรูใหม่ ถ้าคุณไม่สามารถแขวน ASUS ไร้เลส เราเตอร์บนสกรูได้หรือถ้ายึดไว้นานเกินไป

2. การเข้าถึงไร้เลส เราเตอร์

การตั้งค่า IP แอดเดรสสำหรับไคลเอนต์แบบมีสายและไร้สาย

ในการเข้าถึงไร้เลส เราเตอร์ RT-G32 คุณต้องมีการตั้งค่า TCP/IP ที่ถูกต้องบนไคลเอนต์ทั้งแบบมีสาย หรือไร้สายของคุณ ตั้งค่า IP แอดเดรสของไคลเอนต์ภายในช่วงเน็ตเดียวกันของ RT-G32

การรับ IP แอดเดรสโดยอัตโนมัติ

ไร้เลส เราเตอร์ ASUS ประกอบด้วยฟังก์ชัน DHCP เซิร์ฟเวอร์ ดังนั้น PC ของคุณสามารถรับ IP แอดเดรสโดยอัตโนมัติจากไร้เลส เราเตอร์ ASUS ได้



หมายเหตุ: ก่อนที่คุณจะบูต PC ใหม่ ให้เปิดเครื่องไร้เลส เราเตอร์ และตรวจสอบให้แน่ใจว่าเราเตอร์อยู่ในสถานะพร้อมใช้งาน



3. การตั้งค่าคอนฟิกไร้เลส เราเตอร์

ถ้า PC ของคุณเชื่อมต่อไปยังเราเตอร์โดยใช้สายเคเบิล ให้เปิดเว็บเบราว์เซอร์ และหน้าเข้าสู่ระบบของระบบติดต่อบนเว็บของเราเตอร์ จะปรากฏขึ้นโดยอัตโนมัติ

ถ้า PC ของคุณเชื่อมต่อไปยังเราเตอร์แบบไร้สาย คุณต้องเลือกเครือข่ายก่อน

ในการเลือกเครือข่าย:

1. คลิก **Start (เริ่ม) > Control Panel (แผงควบคุม) > Network Connections (การเชื่อมต่อเครือข่าย) > Wireless Network Connection (การเชื่อมต่อเครือข่ายไร้สาย)**
2. เลือกเครือข่ายจากหน้าต่าง **Choose a wireless network (เลือกเครือข่ายไร้สาย)**
รอให้ระบบเชื่อมต่อ



หมายเหตุ: ตามค่าเริ่มต้น SSID ของ RT-G32 คือ **default** เชื่อมต่อไปยัง SSID เริ่มต้นนี้

3. หลังจากการสร้างการเชื่อมต่อไร้สาย ให้เปิดเว็บเบราว์เซอร์

การตั้งค่าคอนฟิกผ่านระบบติดต่อบนเว็บ

1. หลังจากการตั้งค่าการเชื่อมต่อแบบมีสายหรือไร้สาย ให้เปิดเว็บเบราว์เซอร์ หน้าเข้าสู่ระบบ จะปรากฏขึ้นโดยอัตโนมัติ



หมายเหตุ: คุณอาจต้องป้อน IP แอดเดรสของเราเตอร์ (**192.168.1.1**) เข้าไปด้วยตัวเองเพื่อเปิดระบบติดต่อบนเว็บของเราเตอร์

2. บนหน้าเข้าสู่ระบบ ให้ป้อนชื่อผู้ใช้เริ่มต้น (admin) และรหัสผ่าน (admin) เข้าไป
ฟอร์มเพจของ ASUS ไร้เลส เราเตอร์จะปรากฏขึ้น
ฟอร์มเพจจะแสดงลิงค์ด้านเพื่อตั้งค่าคอนฟิกคุณสมบัติหลักของไร้เลส เราเตอร์



หมายเหตุ: สำหรับรายละเอียดเพิ่มเติมเกี่ยวกับคุณสมบัติต่างๆ ของไร้เลส เราเตอร์ ให้อ่านคู่มือผู้ใช้ที่ใหม่ในแผ่น CD สันนิษฐาน



4. การใช้ยูทิลิตี้

การใช้ EZSetup

ในการใช้ EZSetup:

1. จากเดสก์ท็อปของ Windows® ของคุณ, คลิก Start (เริ่ม) > All Programs (โปรแกรมทั้งหมด) > ASUS Utility (ยูทิลิตี้ ASUS) > RT-G32 Wireless Router (RT-G32 ไร้เลส เราเตอร์) > EZSetup Wizard (ตัวช่วยสร้าง EZSetup) เพื่อเปิดยูทิลิตี้ EZSetup
2. ทำตามขั้นตอนบนหน้าจอเพื่อตั้งค่าฮาร์ดแวร์ของคุณ, จากนั้นคลิก Next (ถัดไป)



3. ปฏิบัติตามขั้นตอนบนหน้าจอให้เสร็จ เพื่อทำการติดตั้งให้สมบูรณ์



หมายเหตุ: สำหรับรายละเอียดเพิ่มเติมเกี่ยวกับคุณสมบัติต่างๆ ของไร้เลส เราเตอร์ ให้ดูในคู่มือผู้ใช้ที่หามาในแผ่น CD สัมผัส




5. การตั้งค่าปุ่มด้านของ WPS

เมื่อคุณเชื่อมต่อไร้สาย เราเตอร์ (เช่น ASUS USB-N11 และ PCI-G31 อะแดปเตอร์) กับฟังก์ชัน WPS บนพีซี, โปรดทำตามขั้นตอนด้านล่าง เพื่อเปิดใช้งานการตั้งค่าด้าน WPS

1. เพื่อที่จะใช้ WPS, ตรวจสอบให้แน่ใจว่าทั้ง RT-G32 ไร้สาย เราเตอร์ และฟังก์ชัน WPS ของซอฟต์แวร์ไร้สายของคอมพิวเตอร์เปิดใช้งานอยู่



2. กดปุ่ม WPS ที่แผงด้านหลังของ RT-G32 ไร้สาย เราเตอร์




3. RT-G32 WLAN LED สามารถสว่างขึ้น และกะพริบช้าๆ หลังจากทำการเชื่อมต่อ WPS ถูกสร้างขึ้น





RT-G32

Kablosuz Yönlendirici




Hızlı Başlangıç Kılavuzu




1. Donanımı kurma

Kablolu bağlantı



Kablosuz Bağlantı



Not: Kablosuz bağlantı sağlamak için, IEEE 802.11b/g uyumlu bir WLAN kartı kullanın. Kablosuz bağlantı prosedürleri için kablosuz adaptörü kullanım kılavuzuna bakın.




Takma seçenekleri

Kutudan çıkan ASUS RT-G32 Kablosuz Yönlendirici dosya dolabı ya da kitaplık gibi yüksek ve düz bir yüzeyde durmak için tasarlanmıştır. Ünite aynı zamanda duvar veya tavana monte etmek için dönüştürülebilir.

ASUS RT-G32'yi monte etmek için:

1. İki adet monte çengelinin alt taraflarına bakın.
2. İki adet üst çengeli duvara veya yüksek ve düz bir yüzeye geçirin.
3. İki vidayı sadece 1/4" gözükecek şekilde sıkın.
4. ASUS RT-G32 'nin çengellerini vidalara tutturun .



Not: ASUS Kablosuz Yönlendiriciyi vidalara tutturamazsanız veya çok gevşekse, vidaları yeniden ayarlayın.

2. Kablosuz yönlendiriciye erişme

Kablolu veya kablosuz istemci için IP adresi ayarlama

RT-G32 Kablosuz Yönlendiriciye erişmek için, kablolu veya kablosuz istemcinizde doğru TCP/IP ayarlarına sahip olmalısınız. İstemcilerin IP adreslerini RT-G32 ile aynı alt ağdan ayarlayın.

Otomatik olarak IP adresi Alma

ASUS Kablosuz Yönlendirici DHCP sunucu işlevlerini kullanır, bu yüzde PC'niz ASUS Kablosuz Yönlendiriciden otomatik olarak IP adresi alabilir.



Not: PC'nizi yeniden başlatmadan önce, kablosuz yönlendiriciyi AÇIK ve yönlendiricinin hazır durumda olduğundan emin olun.



3. Kablosuz yönlendiriciyi yapılandırma

PC'niz yönlendiriciye kablo kullanarak bağlanıyorsa, web tarayıcısını başlatın, yönlendiricinin web arayüzünün oturum açma sayfası otomatik olarak çıkar.

PC'niz yönlendiriciye kablosuz olarak bağlanırsa, ilk önce ağı seçmeniz gerekir.

Ağı seçmek için:

1. **Start (Başlat) > Control Panel (Kontrol Paneli) > Network Connections (Ağ Bağlantıları) > Wireless Network Connection (Kablosuz Ağ Bağlantısı)** tıklayın.
2. **Choose a wireless network (Kablosuz ağ seçme)** penceresinden bir ağ seçin. Bağlanmasını bekleyin.



Not: Varsayılan olarak, RT-G32'nin SSID'si **default (varsayılan)** olarak ayarlıdır. Bu varsayılan SSID'ya bağlan.

3. Kablosuz bağlantıyı sağladıktan sonra, web tarayıcısını başlatın.

Web arayüzü ile yapılandırma

1. Kablolü veya kablosuz bağlantı sağladıktan sonra, web tarayıcısını başlatın. Oturum açma sayfası otomatik olarak çıkar.



Not: Yönlendiricinin web arayüzünü başlatmak için yönlendiricinin varsayılan IP adresini manuel olarak girebilirsiniz (**192.168.1.1**).

2. Oturum açma sayfasında, varsayılan kullanıcı adını (**admin**) ve parolayı (**admin**) girin. ASUS Kablosuz Yönlendirici anasayfası çıkar. Anasayfa, kablosuz yönlendiricinin ana özelliklerini yapılandırmak için hızlı bağlantılar gösterir.



Not: Kablosuz yönlendiricinin özellikleri hakkında daha fazla ayrıntı için, destek CD'sinde bulunan kullanım kılavuzuna bakın.




4. Yardımcı Uygulamaların Kullanılması

EZSetup Kullanılması

EZSetup Kullanmak için:

1. Windows® masaüstünüzden, EZSetup yardımcı uygulamasını başlatmak için **Start (Başlat) > All Programs (Tüm Programlar) > ASUS Utility (ASUS Yardımcı Uygulaması) > RT-G32 Wireless Router (RT-G32 Kablosuz Yönlendirici) > EZSetup Wizard (EZSetup Sihirbazı)**'ni tıklayın.
2. Donanınızı kurmak için ekran talimatlarını uyun, daha sonra **Next (İleri)**'yi tıklayın.



3. Kurulumu tamamlamak için gelen ekran talimatlarına uyun.




Not: Kablosuz yönlendiricinin özellikleri hakkında daha fazla bilgi edinmek için, destek CD'sinde bulunan kullanma kılavuzuna bakınız.




5. WPS Hızlı Kurulum Düğmesi

WPS fonksiyonu ile bir bilgisayarın kablosuz adaptör (ASUS USB-N11 ve PCI-G31 adaptör gibi) bağlantısını yaparken, lütfen WPS Hızlı kurulumu etkinleştirmek için aşağıdaki talimatları uygulayın.

1. WPS' yi kullanmak için, hem RT-G32 kablosuz yönlendiricinin hem de diğer bilgisayar kablosuz yazılım WPS fonksiyonunun etkinleştirildiğinden emin olun.



2. RT-G32 kablosuz yönlendiricinin arka panelindeki WPS düğmesine basın.




3. RT-G32 WLAN LED ışığı yanar ve WPS bağlantısı kurulduktan sonra yavaş yavaş yanıp söner.





RT-G32

無線路由器




快速使用指南




1. 設定硬體裝置

有線連接



無線連接



注意：要建立無線連接，請使用相容 IEEE 802.11b/g 無線網路卡。無線連接步驟請參考無線網路卡使用手冊。



安裝無線路由器


華碩無線路由器可安裝在高處的平面上，如衣櫃或書架上，也可以固定於牆上或天花板。

請依據以下步驟安裝華碩無線路由器：

1. 找到路由器底部的兩個安裝掛鉤。
2. 在牆上或高處的平面上標注兩個孔位。
3. 將兩顆螺絲擰緊直到只露出 1/4。
4. 將無線路由器掛到牆上的螺絲上。



注意：若螺絲太鬆或無法將華碩無線路由器掛到螺絲上，請調整螺絲位置。



2. 連接無線路由器

設定有線與無線電腦的 IP 位址

若要與華碩無線路由器連線，您必須在所連線（不論是透過有線或無線的方式連接）的用戶端採用正確的 TCP/IP 設定。請設定使用與華碩無線路相同的子網路（subnet）IP 位址。

自動取得 IP 位址

由於華碩無線路由器支援 DHCP 伺服器功能，因此，您的電腦可自動從華碩無線路由器取得 IP 位址。



注意：在您重新啟動您的個人電腦前，華碩無線路由器必須已開啟並處於待命狀態。



3. 設定無線路由器

若您使用纜線連接電腦與無線路由器，請開啟一個網路瀏覽器，路由器的網頁介面登入畫面會自動出現。

若您使用無線方式連接電腦與路由器，您需要先選擇網路。

請依據以下步驟選擇網路：

1. 點選 **開始 > 控制台 > 網路連線 > 無線網路連線**。
2. 在“選擇一個無線網路”視窗中選擇一個網路。然後等待連線。



注意：預設設定時，無線路由器的 SSID 為 “Default”。連接到此 SSID。

3. 建立無線連接後，開啟一個網路瀏覽器。

透過網頁介面設定

1. 建立有線或無線連接後，開啟一個網路瀏覽器。登入畫面會自動出現。



注意：您可以手動輸入路由器預設 IP 位址（192.168.1.1）來開啟路由器網頁設定畫面。

2. 在登入畫面中，輸入預設使用者名稱（admin）與密碼（admin），接著會出現華碩無線路由器主頁。主頁顯示快速連結，可設定無線路由器的主要功能。



注意：關於路由器功能的詳細資訊，請參考驅動程式與公用程式光碟中的使用手冊。




4. 使用公用程式

使用 EZSetup

請依據以下步驟使用 EZSetup：

1. 點選 開始 > 程式集 > ASUS Utility > RT-G32 Wireless Router > EZSetup Wizard 開啟 EZSetup 公用程式。
2. 請依據螢幕上的指示設定硬體裝置，接著點選 下一步。



3. 請依據螢幕上的指示完成安裝。



注意：要了解更多無線路由器的詳細資訊，請參考驅動程式與公用程式光碟中的使用手冊。




5. WPS 快速鍵設定

當您連接了已安裝支援 WPS 功能的無線網路卡（如：華碩 USB-N11 與 PCI-G31）的電腦時，請依據下列指示開啟 WPS 快速設定。


1. 在使用 WPS 功能之前，請先開啟 RT-G32 無線路由器與另一台電腦的無線軟體 WPS 功能。



2. 按下 RT-G32 無線路由器後面板上的 WPS 鍵。




3. RT-G32 的 WLAN 指示燈亮起，並在建立 WPS 連線後慢閃。





RT-G32

无线路由器




快速使用指南




1. 设置硬件设备

有线连接



无线连接



注意：要建立无线连接，请使用兼容 IEEE 802.11b/g 无线网卡。无线连接步骤请参考无线网卡用户手册。



安装无线路由器


华硕无线路由器可安装在高处的平面上，如衣橱或书架上，也可以固定于墙上或天花板。

请按照以下步骤安装华硕无线路由器：

1. 找到路由器底部的两个安装挂钩。
2. 在墙上或高处的平面上标注两个孔位。
3. 将两颗螺丝拧紧直到只露出 1/4。
4. 将无线路由器挂到墙上的螺丝上。



注意：若螺丝太松或无法将华硕无线路由器挂到螺丝上，请调整螺丝位置。



2. 连接无线路由器

设置有线与无线电脑的 IP 地址

若要与华硕无线路由器连接，您必须在所连接（不论是通过有线或无线的方式连接）的客户端采用正确的 TCP/IP 设置。请设置使用与华硕无线路相同的子网（subnet）IP 地址。

自动取得 IP 地址

由于华硕无线路由器支持 DHCP 服务器功能，因此，您的电脑可自动从华硕无线路由器取得 IP 地址。



注意：在您重新启动您的个人电脑前，华硕无线路由器必须已开启并处于待机状态。



3. 设置无线路由器

若您使用线缆连接电脑与无线路由器，请打开一个网络浏览器，路由器的网页界面登录画面会自动出现。

若您使用无线方式连接电脑与路由器，您需要先选择网络。

请按照以下步骤选择网络：

1. 点击【开始】>【控制面板】>【网络连接】>【无线网络连接】。
2. 在“选择一个无线网络”窗口中选择一个网络。然后等待连接。



注意：默认设置时，无线路由器的 SSID 为 “Default”。连接到此 SSID。

3. 建立无线连接后，打开一个网络浏览器。

通过网页界面设置

1. 建立有线或无线连接后，打开一个网络浏览器。登录画面会自动出现。



注意：您可以手动输入路由器默认 IP 地址（192.168.1.1）来开启路由器网页设置画面。

2. 在登录画面中，输入默认用户名（admin）与密码（admin），接着会出现华硕无线路由器主页。主页显示快捷链接，可设置无线路由器的主要功能。



注意：关于路由器功能的详细信息，请参考驱动程序与应用程序光盘中的用户手册。




4. 使用应用程序

使用 EZSetup

请按照以下步骤使用 EZSetup：

1. 点击【开始】>【所有程序】>【ASUS Utility】>【RT-G32 Wireless Router】>【EZSetup Wizard】开启 EZSetup 应用程序。
2. 请按照屏幕上的指示设置硬件设备，接着点击【下一步】。



3. 请按照屏幕上的指示完成安装。



注意：要了解更多无线路由器的详细信息，请参考驱动程序与应用程序光盘中的用户手册。




5. WPS 快捷键设置

当您连接了已安装支持 WPS 功能的无线网卡（如：华硕 USB-N11 与 PCI-G31）的电脑时，请按照下列指示开启 WPS 快速设置。


1. 在使用 WPS 功能之前，请先开启 RT-G32 无线路由器与另一台电脑的无线软件 WPS 功能。



2. 按下 RT-G32 无线路由器后面板上的 WPS 键。




3. RT-G32 的 WLAN 指示灯亮起，并在建立 WPS 连接后慢闪。





RT-G32

무선 라우터




빠른 시작 안내 설명서




1. 하드웨어 설정

유선 연결



무선 연결



참고 : 무선 연결을 사용하려면 IEEE 802.11b/g 호환 WLAN 카드를 사용해야 합니다 . 무선 연결 절차는 무선 어댑터의 사용자 설명서를 참고해 주십시오 .




마운트 옵션

ASUS 무선 라우터는 기본적으로 파일 캐비닛 또는 책장의 평평한 표면에 설치할 수 있도록 설계되었으며, 벽이나 천정에 마운트 또한 가능합니다.

ASUS 무선 라우터 마운트 방법 :

1. 장치의 바닥 면에 위치한 두 개의 마운팅 홈이 보이도록 해 주십시오.
2. 벽 또는 경사진 평평한 표면에서 설치할 위치에 두 개의 점을 표시해 주십시오.
3. 표시한 곳에 두 개의 나사를 전체의 1/4" 만 보이도록 조여 주십시오.
4. 무선 라우터의 두 홈을 고정된 나사 2 개에 걸쳐 주십시오.



참고 : ASUS 무선 라우터를 나사에 걸 수 없거나 너무 험거울 경우 나사를 다시 조절해 주십시오.

2. 무선 라우터 접속

유 / 무선 클라이언트의 IP 설정

ASUS 무선 라우터에 접속하려면 무선 유선 또는 무선 클라이언트를 위해 TCP/IP 를 올바르게 설정해야 합니다. 클라이언트의 IP 주소를 ASUS 무선 라우터와 같은 서브넷에 위치하도록 설정해 주십시오.

IP 주소 자동으로 얻어오기

ASUS 무선 라우터는 DHCP 서버 기능을 내장하고 있기 때문에 사용자의 PC 는 ASUS 무선 라우터로부터 자동으로 IP 주소를 얻어올 수 있습니다.



참고 : PC 를 재부팅하기 전에 무선 라우터의 전원을 켜서, 라우터가 대기 상태에 있는지 확인해 주십시오.



3. 무선 라우터 구성

사용자의 PC가 케이블을 이용해 연결되어 있을 경우 웹 브라우저를 실행하면 라우터의 웹 인터페이스를 위한 로그인 페이지가 자동으로 나타납니다.

사용자의 PC가 무선으로 연결되어 있을 경우 무선 네트워크를 먼저 선택해야 합니다.

네트워크 선택 방법 :

1. 시작 > 제어판 > 네트워크 연결 > 무선 네트워크 연결을 클릭해 주십시오.
2. 무선 네트워크 연결 창에서 네트워크를 선택하고, 연결되는 동안 잠시 기다려 주십시오.



참고 : 기본적으로 ASUS 무선 라우터의 SSID는 **default**입니다. 이 기본 SSID로 연결해 주십시오.

3. 무선 연결을 완료한 후에 웹 브라우저를 실행해 주십시오.

웹 인터페이스를 통한 구성

1. 유선 또는 무선 연결을 설정한 후에 웹 브라우저를 실행해 주십시오. 로그인 페이지가 자동으로 나타납니다.



참고 : 또한 라우터의 기본 IP 주소 (**192.168.1.1**)를 수동으로 입력하여 라우터의 웹 인터페이스를 실행할 수 있습니다.

2. 로그인 페이지에서 기본 사용자 이름 (**admin**)과 비밀번호 (**admin**)를 입력해 주십시오. ASUS 무선 라우터의 웹페이지가 나타납니다. 웹페이지는 무선 라우터의 주요 기능을 구성하기 위한 빠른 링크를 제공합니다.



참고 : 무선 라우터의 기능에 대한 추가 정보는 지원 CD에 포함된 사용자 설명서를 참고해 주십시오.




4. 유틸리티 사용

EZSetup 사용하기

EZSetup 사용 방법 :

1. Windows® 바탕 화면에서 **시작 > 모든 프로그램 > ASUS Utility > RT-G32 Wireless Router > EZSetup Wizard** 을 클릭하여 EZSetup 유틸리티를 실행해 주십시오 .
2. 이어지는 화면의 지시에 따라 하드웨어를 설정하고 , **Next** 를 클릭해 주십시오 .



3. 이어지는 화면의 지시에 따라 설치를 완료해 주십시오 .




참고 : 무선 라우터의 기능에 대한 추가 정보는 자원 CD 에 포함된 사용자 설명서를 참고해 주십시오 .



5. WPS 빠른 버튼 설정

WPS 기능을 포함하는 무선 어댑터 (ASUS USB-N11 또는 PCI-G31 어댑터 등) 를 PC 에서 사용할 경우 아래 지시에 따라 WPS 빠른 설정을 켜 주십시오 .


1. WPS 를 사용하기 위해 RT-G32 무선 라우터와 다른 컴퓨터의 무선 소프트웨어 WPS 기능이 모두 활성화 된 상태인지 확인해 주십시오 .



2. RT-G32 무선 라우터의 후면부에 위치한 WPS 버튼을 눌러 주십시오 .



3. WPS 연결이 완료되면 RT-G32 WLAN LED 에 불빛이 들어오다가 느리게 깜박이게 됩니다 .



部件名称	有害物质或元素					
	铅 (Pb)	镉 (Cd)	汞 (Hg)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
印刷电路板及零组件	○	○	○	○	○	○
外壳	○	○	○	○	○	○
电源适配器	○	○	○	○	○	○
外部信號連接頭及線材	○	○	○	○	○	○
中央處理器與內存	○	○	○	○	○	○

○：表示该有毒有害物质在该部件所有均质材料中的含量均在SJ/T 11363-2006 标准规定的限量要求以下。

X：表示该有毒有害物质至少在该部件的某一均质材料中的含量超出SJ/T 11363-2006 标准规定的限量要求，然该部件仍符合欧盟指令2002/95/EC的规范。

备注：此产品所标示之环保使用年限，系指在一般正常使用状况下。