


外接硬盘



用户手册

使用硬盘（HDD）



1. 将附赠的 USB 线一端连接到外接硬盘的 USB 端口。
2. 将附赠的 USB 线另一端连接到电脑的 USB 端口。

安装 ASUS+Speed

ASUS +Speed 是一款相当有用的软件，最高可将标准 USB 2.0 / USB 3.0 功能的数据传输速率提升至三倍，实际速率的提升因文件大小、类型及其他因素而异。

请依照以下步骤安装 ASUS +Speed：

1. 将外接硬盘连接到电脑的 USB 端口。开启【我的电脑】并在【有可移动存储的设备】栏位双击 ASUS +Speed 图标。



重要！ 请勿推出或删除两个虚拟分区。这样可能会导致 ASUS +Speed 运行不正常。

2. 点选【选项】以选择安装路径。选择您偏好的语言，接着勾选下面的信息以表示您已阅读并接受许可条款。点选【下一步】以继续。



3. 输入序列号。您可以在快速使用指南（QSG）上找到该序列号。接着点选【安装】。



4. 稍候片刻等待 ASUS +Speed 安装完成。安装完成后点选【完成】。



使用 ASUS+Speed

请依照以下步骤使用 ASUS +Speed：

1. 将外接硬盘连接到您电脑的 USB 端口。ASUS +Speed 会自动启动。
2. 从以下模式中选择其一：
 - +Speed：选择此模式以获得更快的数据传输速率。
 - Normal：选择此模式以获得正常的数据传输速率。
3. 现在您可以开始在电脑和外接硬盘之间复制数据了。



安全移除硬盘

请依照以下步骤安全移除硬盘：


1. 从 ASUS +Speed 画面，点选硬盘图标上的连接线。



2. 在确认信息出现时点选【是】。



3. 当硬盘图标中的连接线显示为断开时，代表您已安全移除硬盘。



ASUS +Speed 测试环境

平台	
处理器	Intel Core i5 650
主板	华硕 P7H55-M/USB3
内存	DDR 1333 2GB
硬盘	ST3500418AS SATA
系统软件与驱动程序	
软件	ASUS +Speed 1.0
操作系统	Windows 7 64-bit Ultimate
驱动程序	U3 NEC Onboard Driver 1.0.19.0
外部设备	ST9500325AS 5400RPM



注意：

- 在上述测试环境下，ASUS +Speed 可将标准 USB 2.0 / USB 3.0 功能的数据传输速率提升至三倍。
- ASUS +Speed 的测试传输速率因系统环境、文件大小、文件类型及其他因素而异。

注意事项



This is a Class B product, in a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.

REACH

Complying with the REACH (Registration, Evaluation, Authorisation, and Restriction of Chemicals) regulatory framework, we published the chemical substances in our products at ASUS REACH website at <http://csr.asus.com/english/index.aspx>



CAUTION! DO NOT throw the external hard drive in municipal waste. This product has been designed to enable proper reuse of parts and recycling. This symbol of the crossed out wheeled bin indicates that the product (electrical and electronic equipment) should not be placed in municipal waste. Check local regulations for disposal of electronic products.

ASUS Recycling/Takeback Services

ASUS recycling and takeback programs come from our commitment to the highest standards for protecting our environment. We believe in providing solutions for you to be able to responsibly recycle our products, batteries, other components, as well as the packaging materials. Please go to <http://csr.asus.com/english/Takeback.htm> for the detailed recycling information in different regions.



Manufacturer:	ASUSTeK Computer Inc. Tel: +886-2-2894-3447 Address: No. 150, LI-DE RD., PEITOU, TAIPEI 112, TAIWAN
Authorised representative in Europe:	ASUS Computer GmbH Address: HARKORT STR. 21-23, 40880 RATINGEN, GERMANY
Authorised distributors in Turkey:	BOGAZICI BİL GİSAYAR SAN. VE TİC. A.Ş. Tel: +90 212 3311000 Address: AYAZAGA MAH. KEMERBURGAZ CAD. NO.10 AYAZAGA/İSTANBUL CİZGİ Elektronik San. Tic. Ltd. Şti. Tel: +90 212 3567070 Address: CEMAL SURURİ CD. HALİM MERİÇ İS MERKEZİ No: 15/C D:5-6 34394 MECİDİYEKÖY/İSTANBUL

EEE Yönetmeliğine Uygundur.