

External Hard Disk Drive



User Manual

Using the hard disk drive (HDD)



1. Connect one end of the bundled USB cable to the external hard drive's USB port.
2. Connect the other end of the bundled USB cable to your computer's USB port.

Installing ASUS+Speed

ASUS +Speed is a software that accelerates the standard USB 2.0 / USB 3.0 function to up to three times its transfer speed, which may vary depending on file size, type, and other factors.

To install ASUS +Speed:

1. Connect the external hard drive to your computer's USB port. Launch **My Computer** and double-click the ASUS +Speed icon in the **Devices with Removable Storage** field.



IMPORTANT! Do not eject or delete the two virtual partitions. Doing so may cause ASUS +Speed to malfunction.

Using ASUS+Speed

To use ASUS +Speed:

1. Connect the external hard drive to your computer's USB port. ASUS +Speed automatically launches.
2. Select from any of these modes:
 - **+Speed:** Select this mode for a faster data transfer rate.
 - **Normal:** Select this mode for a normal data transfer rate.
3. You can now start copying files from your computer to your external hard drive and vice versa.



Safely removing the HDD

To safely remove the HDD:


1. From the ASUS +Speed screen, click the cable on the HDD icon.



2. Click **Yes** on the confirmation message.



3. When the HDD icon with a broken cable is shown, you can now safely remove the HDD.



ASUS +Speed Testing Environment

Platform	
CPU	Intel Core i5 650
Motherboard	ASUS P7H55-M/USB3
Memory module	DDR 1333 2GB
Hard disk drive	ST3500418AS SATA
System Software & Drivers	
Software	ASUS +Speed 1.0
Operating system	Windows 7 64-bit Ultimate
Driver	U3 NEC Onboard Driver 1.0.19.0
External enclosure	ST9500325AS 5400RPM



NOTES:

- Under the testing environment mentioned above, ASUS +Speed accelerated the standard USB 2.0 / USB 3.0 function to up to three times its transfer speed.
- ASUS +Speed's resulting transfer speed varies with the system environment, file size, file type, and other factors.

Notices

CE Mark Warning

This is a Class B product, in a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.



REACH

Complying with the REACH (Registration, Evaluation, Authorisation, and Restriction of Chemicals) regulatory framework, we published the chemical substances in our products at ASUS REACH website at <http://csr.asus.com/english/index.aspx>



CAUTION! DO NOT throw the external hard drive in municipal waste. This product has been designed to enable proper reuse of parts and recycling. This symbol of the crossed out wheeled bin indicates that the product (electrical and electronic equipment) should not be placed in municipal waste. Check local regulations for disposal of electronic products.

ASUS Recycling/Takeback Services

ASUS recycling and takeback programs come from our commitment to the highest standards for protecting our environment. We believe in providing solutions for you to be able to responsibly recycle our products, batteries, other components, as well as the packaging materials. Please go to <http://csr.asus.com/english/Takeback.htm> for the detailed recycling information in different regions.

Manufacturer:	ASUSTeK Computer Inc. Tel: +886-2-2894-3447 Address: No. 150, LI-DE RD., PEITOU, TAIPEI 112, TAIWAN
Authorised representative in Europe:	ASUS Computer GmbH Address: HARKORT STR. 21-23, 40880 RATINGEN, GERMANY
Authorised distributors in Turkey:	BOGAZICI BIL GISAYAR SAN. VE TIC. A.S. Tel: +90 212 3311000 Address: AYAZAGA MAH. KEMERBURGAZ CAD. NO.10 AYAZAGA/ ISTANBUL CIZGI Elektronik San. Tic. Ltd. Sti. Tel: +90 212 3567070 Address: CEMAL SURURI CD. HALIM MERIC IS MERKEZI No: 15/C D:5-6 34394 MECIDIYEKOY/ISTANBUL