


## 외장 하드 디스크 드라이브



## 사용자 설명서

## 하드 디스크 드라이브(HDD) 사용



1. 포장된 USB 케이블의 한 쪽 끝을 외장 하드 드라이브의 USB 포트에 연결하십시오.
2. 포장된 USB 케이블의 다른 한 쪽 끝을 컴퓨터의 USB 포트에 연결하십시오.

## ASUS+Speed 설치

ASUS +Speed는 표준 USB 2.0 / USB 3.0 기능의 전송 속도를 세 배 높여 주는 소프트웨어입니다. 전송 속도는 파일 크기, 형식 및 기타 요소에 따라 달라질 수 있습니다.

ASUS +Speed 설치:

1. 외장 하드 드라이브를 컴퓨터의 USB 포트에 연결합니다. My Computer(내 컴퓨터)를 실행한 후 Devices with Removable Storage(이동식 미디어 장치) 필드에서 ASUS +Speed 아이콘을 두 번 클릭합니다.



**중요!** 두 개의 가상 파티션을 꺼내거나 삭제하지 마십시오. 꺼내거나 삭제할 경우 ASUS +Speed가 오작동할 수 있습니다.

2. Options(옵션)를 클릭하여 설치 경로를 선택합니다. 선호하는 언어를 선택한 후 사용권 계약을 읽었으며 이에 동의함을 확인하는 메시지를 선택합니다. Next(다음)를 클릭하여 계속합니다.



3. 빠른 시작 설명서에 나와 있는 일련번호를 입력한 후 Install(설치)을 클릭합니다.



4. ASUS +Speed 설치가 완료될 때까지 잠시 기다립니다. 설치 과정이 완료되면 Done(완료)을 클릭합니다.



## ASUS+Speed 사용

### ASUS +Speed 사용:

1. 외장 하드 드라이브를 컴퓨터의 USB 포트에 연결합니다.  
ASUS +Speed가 자동으로 실행됩니다.
2. 다음 모드 중에서 선택합니다:
  - +속도: 더 빠른 전송 속도를 원할 경우 이 모드를 선택합니다.
  - 보통: 보통의 전송 속도를 원할 경우 이 모드를 선택합니다.
3. 이제 파일을 컴퓨터에서 외장 하드 드라이브로 또는 외장 하드 드라이브에서 컴퓨터로 복사할 수 있습니다.



## HDD의 안전한 제거

### HDD의 안전한 제거:


1. ASUS +Speed 화면에서 HDD 아이콘의 케이블을 클릭합니다.



2. 확인 메시지가 표시되면 Yes(예)를 클릭합니다.



3. HDD 아이콘과 끊어진 케이블이 표시되면, HDD를 안전하게 제거할 수 있습니다.



## ASUS +Speed 시험 환경

플랫폼	
CPU	Intel Core i5 650
마더보드	ASUS P7H55-M/USB3
메모리 모듈	DDR 1333 2GB
하드 디스크 드라이브	ST3500418AS SATA
시스템 소프트웨어 및 드라이버	
소프트웨어	ASUS +Speed 1.0
운영 체제	Windows 7 64 비트 Ultimate
드라이버	U3 NEC 보드 내장 드라이버 1.0.19.0
외부 함체	ST9500325AS 5400RPM




### 참고:

- 위에서 언급한 시험 환경에서 ASUS +Speed는 표준 USB 2.0 / USB 3.0 기능의 전송 속도를 세 배 높였습니다.
- 이에 따른 ASUS +Speed의 전송 속도는 시스템 환경, 파일 크기, 파일 형식 및 기타 요인에 따라 다릅니다.

## Notices



This is a Class B product, in a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.



## REACH

Complying with the REACH (Registration, Evaluation, Authorisation, and Restriction of Chemicals) regulatory framework, we published the chemical substances in our products at ASUS REACH website at <http://csr.asus.com/english/index.aspx>



**CAUTION!** DO NOT throw the external hard drive in municipal waste. This product has been designed to enable proper reuse of parts and recycling. This symbol of the crossed out wheeled bin indicates that the product (electrical and electronic equipment) should not be placed in municipal waste. Check local regulations for disposal of electronic products.

## ASUS Recycling/Takeback Services

ASUS recycling and takeback programs come from our commitment to the highest standards for protecting our environment. We believe in providing solutions for you to be able to responsibly recycle our products, batteries, other components, as well as the packaging materials. Please go to <http://csr.asus.com/english/Takeback.htm> for the detailed recycling information in different regions.

Manufacturer:	ASUSTeK Computer Inc. Tel: +886-2-2894-3447 Address: No. 150, LI-DE RD., PEITOU, TAIPEI 112, TAIWAN
Authorised representative in Europe:	ASUS Computer GmbH Address: HARKORT STR. 21-23, 40880 RATINGEN, GERMANY
Authorised distributors in Turkey:	BOGAZICI BIL GISAYAR SAN. VE TIC. A.S. Tel: +90 212 3311000 Address: AYAZAGA MAH. KEMERBURGAZ CAD. NO.10 AYAZAGA/ISTANBUL  CIZGI Elektronik San. Tic. Ltd. Sti. Tel: +90 212 3567070 Address: CEMAL SURURI CD. HALIM MERIC IS MERKEZI No: 15/C D:5-6 34394 MECIDIYEKÖY/ISTANBUL