

Eee PC

Priročnik za uporabo

Windows® 7 Izdaja
Eee PC VX6S



Kazalo

Kazalo	ii
O navodilih za uporabo	iv
Opozorila v navodilih	iv
Varnostna opozorila	v
Varnostni ukrepi pri prenosu	vi
Polnjenje baterij	vii
Varnostni ukrepi na letalu	vii
Opozorilo pred zvočnim tlakom	vii

Poglavlje 1: Spoznavanje delov

Zgornji del	1-2
Spodnji del	1-5
Sprednji del	1-6
Desni del	1-7
Levi del	1-8
Uporaba tipkovnice	1-10
Posebne funkcijске tipke	1-10
Uporaba sledilne tablice	1-12
Večprstni vnos	1-12

Poglavlje 2: Namestitev

Napajanje Eee PC	2-2
Prvi zagon	2-3
Namizje	2-5
Omrežna povezava	2-6
Konfiguracija povezave v brezščično omrežje	2-6
Lokalno omrežje	2-7
Brskanje po spletnih straneh	2-10

Poglavlje 3: Uporaba Eee PC

Posodobitev ASUS	3-2
Posodabljanje BIOS-a preko interneta	3-2
Posodabljanje BIOS-a preko datoteke BIOS	3-3
Povezava Bluetooth (na izbranih modelih)	3-4

Super hibridni mehanizem	3-6
Super hibridni mehanizem Modes (Načini super hibridnega mehanizma).....	3-6
Eee Docking (na izbranih modelih)	3-7
Access	3-7
Sharing	3-8
Experience	3-8
Tools	3-8
Instant On (na izbranih modelih).....	3-9
Opomba glede polnjenja zunanjih naprav prek vrat USB.....	3-9
Microsoft® Office Starter 2010.....	3-10

Poglavlje 4: Obnovitev sistema

Obnovitev sistema.....	4-2
------------------------	-----

Dodatek

Deklaracije in varnostne izjave.....	D-2
Informacije o avtorskih pravicah	D-20
Omejitev odgovornosti.....	D-21
Storitev in podpora.....	D-21

O navodilih za uporabo

V rokah imate Navodila za uporabo Eee PC. V navodilih za uporabo boste našli informacije o različnih komponentah Eee PC in njihovi uporabi. Navedena so glavna poglavja v navodilih za uporabo:

1. Spoznavanje delov

Predstavi informacije o komponentah Eee PC.

2. Namestitev

Predstavitev informacij o namestitvi Eee PC.

3. Uporaba Eee PC

Vsebuje informacije o uporabi orodij Eee PC.

4. Obnovitev sistema

Podaja informacije o obnovitvi sistema.

5. Dodatek

Vsebuje varnostne predpise.



Dejanske vključene aplikacije se razlikujejo glede na model in območje. Zato lahko prihaja do razlik med vašim računalnikom Eee in tistim, ki je prikazan na fotografijah v priročniku. Prosimo upoštevajte, da je vaš Eee PC pravilen.

Opozorila v navodilih

V navodilih so navedena opombe in opozorila na katere morate biti pozorni za pravilno in varno izvedbo določenih opravil. Opozorila imajo več stopenj pomembnosti, kot prikazano spodaj:



OPOZORILO! Pomembne informacije, ki jih je potrebno upoštevati za varno delovanje.



POMEMBNO! Pomembne informacije, ki jih je potrebno upoštevati za preprečitev poškodb na podatkih, komponentah ali osebah.



NASVET: Nasveti in uporabne informacije za dokončanje nalog.



OPOMBA: Namig in informacija za posebne primere.

Varnostna opozorila

Navedena varnostna opozorila bodo podaljšala življenje Eee PC. Upoštevajte vsa opozorila in navodila. Razen, če navedeno v navodilih, vsa popravila predajte kvalificiranemu osebju. Ne uporabljajte poškodovanih kablov, dodatkov ali ostalih periferij. Ne uporabljajte močnih kemikalij kot so razredčila, bencin ali ostale kemikalije na ali blizu površine.



Pred čiščenjem izklopite AC napajanje ali odstranite baterije. Za čiščenje Eee PC uporabite čisto mehko krpo ali jelenjo krpico, namočeno v raztopino neagresivnega čistila in nekaj kapljic tople vode in odstranite odvečno tekočino z suho krpo.



NE postavljajte na neravno ali nestabilno delovno površino. Če je površina poškodovana, se obrnite na servis.



NE postavljajte ali mečite predmetov na površino in ne vstavljamte predmetov v Eee PC.



NE izpostavljajte umazanemu ali prašnemu okolju. NE uporabljajte v primeru uhajanju plina.



NE izpostavljajte močnim magnetnim ali električnim poljem.



NE pritiskajte in ne dotikajte se ekranu. NE postavljajte skupaj z manjšimi predmeti, ki lahko opraskajo ali zaidejo v Eee PC.



NE izpostavljajte in ne uporabljajte v bližini tekočin, dežja ali vlage. NE uporabljajte modema med nevihto.



NE postavljajte Eee PC v naročje ali na drug del telesa, da preprečite neudobje ali poškodbe zaradi izpostavitve toploti.



Opozorilo o varni uporabi baterij: NE mečite baterij v ogenj. NE izpostavljajte vhodov kratkemu stiku. NE razstavljajte baterij.



VARNA TEMP: Eee PC uporabljajte v okoljih s temperaturo med 5°C (41°F) in 35°C (95°F)



VSTOPNA JAKOST: Upoštevajte nalepko z navedeno jakostjo na spodnji strani Eee PC in preverite, da je vaš kabel za priklop primeren navedeni jakosti.



NE prenašajte ali zakrivajte Eee PC, ki je vklopljen z materiali, ki bi zmanjšali zračenje, kot je npr. plastična vrečka.



Nepravilna namestitev baterije lahko povzroči eksplozijo in poškoduje Eee PC.



NE mečite Eee PC na javno smetišče. Ta izdelek je bil zasnovan tako, da omogoča ponovno uporabo delov in recikliranje. Simbol prekrižanega smetnjaka nakazuje, da se izdelek (električna, elektronska oprema in baterije, ki vsebujejo živo srebro) ne sme odlagati na javno smetišče. Preverite lokalne predpise, ki določajo odstranitev elektronskih izdelkov.



NE zavrzite baterije med komunalne odpadke. Simbol prekrižanega smetnjaka ponazarja, da se baterij ne sme odlagati skupaj s komunalnimi odpadki.

Varnostni ukrepi pri prenosu

Da pripravite Eee PC na prenos, ga izklopite in **odklopite vse zunanje periferije za preprečitev poškodb na povezavah**. Glava na pogonu za trdi disk se ustavi, kadar se računalnik izklopi, zato da se preprečijo poškodbe na površini trdega diska med prenosom. **Zato Eee PC, ki je še vedno vklopljen, ne smete prenašati.** Zaprite zaslone in preverite, da je varno pritrjen v zaprttem položaju, saj se tako zaščiti tipkovnica in zaslone.

Površina računalnika je ob napačni skrbi zelo občutljiva za poškodbe. Zato pri prenašanju Eee PC pazite, da ga ne boste odrgnili. Eee PC lahko shranite v torbico za prenašanje in ga tako zavarujete pred nečistočami, vodo, udarci in praskami.

Polnjenje baterij

Pred odhodom na daljšo pot preverite, če ste baterijo in rezervne baterije temeljito napolnili. Ne pozabite, da vaš napajalni adapter polni baterije le v primeru, ko je priključen na računalnik in AC kabel. Ne pozabite, da je polnjenje baterij daljše v primeru, ko je Eee PC v uporabi.

Upoštevajte, da morate pred prvo uporabo baterijo popolnoma napolniti (polnите jo 8 ur ali več), saj to podaljša njeno življenjsko dobo. Baterija doseže svojo maksimalno kapaciteto šele po nekaj ciklih popolnega napolnjenja in izpraznjenja.

Varnostni ukrepi na letalu

Če želite uporabiti Eee PC na letalu se obrnite na vaše letalsko podjetje. Večina letalskih podjetij omejuje uporabo elektronskih naprav. Večina letalskih podjetij bo dovolila uporabo elektronskih naprav samo med letenjem, ne pa med vzletanjem in pristajanjem.



Obstajajo tri vrste letaliških varnostnih naprav: Rentgenska naprava (uporabljeni na predmetih, ki so postavljeni na tekoči trak), magnetni detektorji (uporabljeni na ljudeh, ki gredo skozi varnostni pregled) in magnetne palice (ročne naprave za pregled ljudi in posameznih predmetov). Vaš Eee PC in diskete lahko pošljete skozi rentgensko napravo. Ni priporočeno, da se na vašem Eee PC in disketami uporabi letališki magnetni detektor ali izpostavi magnetni palici.

Opozorilo pred zvočnim tlakom

Opozorilo: Prekomerna glasnost slušalk lahko povzroči poškodbo ali izgubo sluha. Prilagajanje glasnosti in izenačevalnika na druge nastavitev, kot na sredino, lahko povišajo izhodno napetost slušalk in s tem tudi nivo zvočnega tlaka.

Zgornji del

Spodnji del

Sprednji del

Desni del

Levi del

Uporaba tipkovnice

Uporaba sledilne tablice

1


Spoznavanje delov

Zgornji del

Za prepoznavanje komponent na tej strani Eee PC, si oglejte spodnji diagram.



Zgornja stran se pri posameznih modelih lahko razlikuje.



Tipkovnica je za vsako področje drugačna.

- 1**  **Vgrajena kamera**
- 2**  **Mikrofon (vgrajen)**
- 3**  **Zaslon**
- 4**  **Gumb Express Gate Button (na izbranih modelih)**

Ko je Eee PC ugasnjen, boste s pritiskom na ta gumb aktivirali Express Gate. Express Gate je ekskluzivni operacijski sistem ASUS, ki vam omogoča hiter dostop do Interneta in do ključnih aplikacij, ne da bi bilo treba vstopiti v OS Windows®.

Gumb za napajanje Super Hybrid

V OS Windows ta gumb deluje kot gumb za napajanje Super Hybrid. Gumb omogoča preklapljanje med različnimi načini varčevanja z energijo. Funkcijo lahko nadzorujete tudi s pritiskom **<Fn> + <Space Bar>**.

- 5**  **Tipka za vklop (Windows)**

Stikalo za vklop omogoča VKLOP in IZKLOP Eee PC, pa tudi ponovno vzpostavitev iz način pripravljenosti. Za VKLOP Eee PC, pritisnite tipko enkrat, za IZKLOP jo pritisnite in zadržite. Stikalo za vklop deluje le, če je zaslon odprt.

Indikator vklopa

Indikator vklopa zasveti, ko VKLJUČITE Eee PC, ter počasi utripa, ko je Eee PC v načinu »Sleep« (Spanje). Ko je Eee PC IZKLOPLJEN, je ta indikator IZKLOPLJEN.

- 6**  **Tipkovnica**
- 7**  **Dotikalna plošča in tipke**
- 8**  **Indikatorji stanja**

Indikator vklopa

Indikator vklopa zasveti, ko VKLJUČITE Eee PC, ter počasi utripa, ko je Eee PC v načinu »Sleep« (Spanje). Ko je Eee PC IZKLOPLJEN, je ta indikator IZKLOPLJEN.

Kazalec polnjenja baterije

Kazalec polnjenja baterije je LED, ki prikazuje status stanja baterije, kot je:

VKLOPLJENO

	Z napajalnim adapterjem	Brez napajalnega adapterja
Polno napolnjena baterija (95 % - 100 %)	SVETI zeleno	Ne sveti
Srednje napolnjena baterija (11 % - 94 %)	SVETI oranžno	Ne sveti
Nizko napolnjena baterija (0 % - 10 %)	Utripajoče oranžno	Utripajoče oranžno

Brez napajanja/način pripravljenosti

	Z napajalnim adapterjem	Brez napajalnega adapterja
Polno napolnjena baterija (95 % - 100 %)	SVETI zeleno	Ne sveti
Srednje napolnjena baterija (11 % - 94 %)	SVETI oranžno	Ne sveti
Nizko napolnjena baterija (0 % - 10 %)	Utripajoče oranžno	Ne sveti

Indikator trdega diska (HDD)

Indikator trdega diska utripa, kadar se nanj zapisujejo podatki ali poteka njihovo branje.

Kazalec brezžičnega omrežja/Bluetooth

To je mišljeno samo na modelih, ki imajo vgrajen brezžični LAN/Bluetooth (na izbranih modelih). Kadar je brezžični LAN/Bluetooth omogočen, se priže lučka.

Kazalec zaklopa velikih črk


Prikaže, da je zaklop velikih črk [Num Lk] aktiviran, kadar gori lučka.

Spodnji del

Za prepoznavanje komponent na tej strani Eee PC, si oglejte spodnji diagram.



Spodnji del se navzven razlikuje glede na model.



Spodnji del Eee PC lahko postane zelo vroč. Bodite previdni z upravljanjem Eee PC, kadar je vklopljen ali je bil nedavno vklopljen. Visoke temperature so normalne med napajanjem ali kadar je v delovanju. NE UPORABLJAJTE GA NA MEHKIH POVRŠINAH KOT SO POSTELJA ALI ZOFA, KJER LAHKO PRIDE DO ZAPRTJA ZRAČNIKOV. **NE POSTAVLJAJTE Eee PC V VAŠE NAROČJE ALI OSTALE DELE TELESA, ZATO DA SE IZOGNETE POŠKODBAM ZARADI VROČINE.**



Baterija

Trajanje baterije je odvisno od uporabe in specifikacij tega Eee PC. Baterija se ne sme razstaviti in se mora kupiti kot skupna enota.

2 **Zaklep baterije**


Zaklep baterije varuje baterijo. Če je baterija pravilno nameščena, se samodejno zaskoči na svoje mesto. Za odstranite baterije zaklep baterije potisnite navznoter.

3 **Predel pomnilnika (RAM)**

Pomnilniški modul je zavarovan v posebnem predelu.

Sprednji del

Za prepoznavanje komponent na tej strani Eee PC, si oglejte spodnji diagram.




1 **Avdio zvočniki**

Zvočne možnosti nadzoruje program.

Desni del

Za prepoznavanje komponent na tej strani Eee PC, si oglejte spodnji diagram.



① Vtičnica za slušalke

② Priključek za mikrofon

Priključek za mikrofon je namenjen za priklop mikrofona za uporabo aplikacije glasovnih narek ali enostavnih zvočnih posnetkih.

③ USB vhod (3.0)



Vrata USB (univerzalno serijsko vodilo) so združljiva z napravami USB 3.0, 2.0 ali USB 1.1, kot so tipkovnice, kazalne naprave, kamere in naprave za shranjevanje. Dejanska hitrost prenosa se lahko razlikuje, glede na vrata USB in napravo, ki jo uporabljate.

④ LAN vhod (10/100M bitov)


RJ-45 LAN vrata z osmimi nožicami podpirajo standardni ethernet kabel za povezavo v lokalno omrežje.

⑤ Kensington® varnostna vrata

Kensington® varnostna vrata omogočajo, da je Eee PC zavarovan z uporabo kompatibilnih Kensington® -vih varovalnih naprav. Te varovalne naprave vključujejo kovinski kabel in ključavnico, ki preprečujejo, da se Eee PC odstrani s pritrjenega predmeta.

Levi del

Za prepoznavanje komponent na tej strani Eee PC, si oglejte spodnji diagram.



1 **Vhod za napajanje (DC)**

S to vtičnico, obstoječi vtič za vklop spremeni AC napajanje v DC napajanje. Energija, ki prihaja skozi to vtičnico omogoča delovanje Eee PC in polni notranjo baterijo. Za preprečitev poškodb na Eee PC in bateriji za vklop vedno uporabljajte obstoječo vtičnico.



MED UPORABO SE LAJKO SEGREJE IN POSTANE VROČE.
PREVERITE DA ADAPTER NI ZAKRIT IN GA NE PRIBLIŽUJTE TELESU.

2 **15-pinski D-Sub izhod zaslona (monitorja)**

3 **Izhod HDMI**



Ne pozabite odklopiti kabla HDMI, ko uporabljate računalnik Eee kot glavno napravo za predvajanje video in zvočnih vsebin.

4 **USB vhod (2.0/1.1)**

USB Charge+

Vam omogoča polnjenje mobilnih telefonov ali digitalnih zvočnih predvajalnikov, medtem ko je računalnik Eee v stanju spanja, mirovanja ali pa je ugasnjén. Zaženite aplikacijo USB Charge+ z orodne vrstice Eee Docking ter nastavite ustrezne nastavitev.

5 Prezračevalne reže

Prezračevalne reže omogočajo vstop hladnega zraka v Eee PC in izstop toplega zraka iz njega.



Preverite, da papirji, knjige, oblačila, kabli ali ostali predmeti ne blokirajo kateregakoli od zračnikov, saj lahko pride do pregrevanja.

6 Reža za spominsko kartico

Vgrajeni čitalnik spominskih kartic lahko bere kartice vrst SD/SDHC/SDXC/MMC .

Uporaba tipkovnice

Posebne funkcijске tipke

Sledče določi obarvane vroče tipke na tipkovnici Eee PC. Do obarvanih tipk z ukazi je mogoče priti najprej s pritiskom in držanjem funkcijске tipke, medtem ko pritisnemo na tipko z obarvanim ukazom. Po aktivaciji se v območju za obvestila pojavijo nekatere ikone delovanja.



Postavitev vročih tipk na funkcionalnih tipkah lahko variira glede na model, toda funkcije ostanejo iste. Sledi ikonam namesto funkcijskim tipkam.



Z² Ikona (F1): Postavi Eee PC v stanje pripravljenosti (Save-to-RAM).



Radio Tower (F2) (Samo za brezžične modele): Poišče notranji brezžični LAN ali Bluetooth (pri izbranih modelih) vklop in izklop s prikazom na ekranu. Ko je omogočen, se bo posvetil kazalec za najdeno brezžično povezavo.



Ikona s sončnim zahodom (F5): Zmanjša svetlost ekrana.



Ikona s sončnim vzhodom (F6): Poveča svetlost ekrana.



Ikona prekrižanega zaslona (F7): Vklopi ali izklopi osvetlitev ozadja zaslona.



LCD/Monitor Ikona (F8): Preklaplja med LCD ekranom Eee PC in zunanjim monitorjem.



Ploščica na dotik (F9): Preklopi med možnostma VKLOP/IZKLOP.



Ikona s prekrižanimi zvočniki (F10): Utiša zvočnik.



Ikona zmanjšanje glasnosti zvočnika (F11): Zmanjša glasnost zvočnika.



Ikona povečanja glasnosti zvočnika (F12): Poveča glasnost zvočnika.



Super hibridni mehanizem (Preslednica): Preklopi med različnimi načini varčevanja z energijo. Izbrani način je prikazan na zaslonu.



Num Lk (Vstavi): VKLOPI/IZKLOPI številčno tipkovnico zaklep številk). Omogoča uporabo večjega dela tipkovnice pri vnašanju števil.



Scr Lk (Izbriši): Preklopi "Zapora premikanja" na vklop in izklop. Omogoča večji del tipkovnice za premikanje po celicah.



Predvajaj/Prekini predvajanje (↓)

Začne ali prekine predvajanje medijske datoteke.



Ustavi predvajanje(↑)

Zaustavi predvajanje medijske datoteke.



Nazaj (←)

Med predvajanjem medijske datoteke se vrne na prejšnji posnetek / poglavje filma.



Naprej (→)

Med predvajanjem medijske datoteke preskoči na naslednji posnetek / poglavje filma.



V: Vklopi (ON) aplikacijo kamere.



C: Vklopi (ON) ohranjevalnik zaslona.



Ikona Windows: Prikaz zagonskega menija.





Meni z ikono kazalnika: Aktivira meni z lastnostmi je enakovreden desnemu kliku sledilne tablice/miške na predmet.


Uporaba sledilne tablice

Večprstni vnos


Dvoprstno povečanje/pomanjšanje - Pomik dveh prstov skupaj ali narazen po sledilni tablici poveča ali pomanjša prikaz na zaslonu. To je še posebej pripravno pri ogledu fotografij ali branju dokumentov.




Dvoprstno vrtenje - Položite en prst na sledilno tablico, nato pa z drugim prstom napravite lok in tako zavrtite fotografijo ali dokument, ki ga gledate. Glede na vaše potrebe lahko predmet zavrite v desno ali v levo.



Dvoprstno pomikanje gor/dol ali levo/desno- Z dvema prstoma podrsajte navzgor/navzdol ali levo/desno na sledilni tablici in tako pomaknite okno gor/dol oz. levo/desno. Če vaše prikazano okno vsebuje več podoken, pred pomikanjem premaknite kazalec na želeno podokno.



Triprstni premik na prejšnjo/naslednjo stran- S tremi prsti se horizontalno premaknite po sledilni tablici in tako premaknite stran. Podrsajte od leve proti desni za ogled naslednje strani oz. od desne proti levi za ogled prejšnjih strani.



Napajanje Eee PC

Prvi zagon

Namizje


Omrežna povezava

Namestitev 


Napajanje Eee PC

To so le hitra navodila za uporabo Eee PC.


1. Namestite baterijo



2. Povežite napajalni adapter



3. VKLOPITE Eee PC



Če boste uporabljali druge napajalne adapterje, se Eee PC lahko poškoduje. Zaradi uporabe napačnega napajalnega adapterja lahko poškodujete tako baterijo, kot tudi Eee PC.



- Ko odprete zaslon, ga ne pritisnite skrajno v zadnji položaj, protimizi, sicer se vodila lahko zlomijo! Eee PC nikoli ne dvigujte za zaslon!
- Uporabite samo baterije in vtičnice, ki so bile priložene Eee PC, ali pa so bile posebej odobrene s strani proizvajalca ali trgovca za uporabo na tem modelu, saj lahko na Eee PC pride do poškodb. Območje vhodne napetosti med stensko vtičnico in tem adapterjem je AC 100 V ~ 240 V, izhodna napetost tega adapterja pa je +19 Vdc, 2,1 A.
- Nikoli ne odstranite baterije v času, ko je Eee PC vklopljen, saj lahko to povzroči izgubo podatkov.



Upoštevajte, da morate pred prvo uporabo baterijo popolnoma napolniti (polnite jo 8 ur ali več), saj to podaljša njeno življenjsko dobo.

Prvi zagon


Ob prvem zagonu Eee PC se bo samodejno zagnal čarownik Windows, ki vas bo vodil skozi postopek osebnih nastavitev in vnos osnovnih informacij.

Za dokončanje inicializacije sledite navodilom čarownika:


1. Izberite želeni jezik. Kliknite **Naprej** za nadaljevanje.
2. Z nastavljivo regijo, časovnega pasu in vrste tipkovnice boste opravili osnovne nastavitev vašega sistema. Kliknite **Naprej** za nadaljevanje.



3. Vnesite ime svojega uporabniškega računa in ime računalnika, nato kliknite **Naprej** za nadaljevanje.




- 5. Preberite si licenčno pogodbo in kliknite polji pred **Sprejmem licenčne pogoje**. Kliknite Naprej za nadaljevanje.**




- 6. Za pridobitev najnovejših pomembnih posodobitev kliknite **Uporabi priporočene nastavitev**.**




- 7. Določite časovno pas in lokalni datum ter uro. Kliknite Naprej za nadaljevanje.**



- 8. Povežite se v brezžično omrežje in kliknite Naprej za nadaljevanje ali Preskoči, če boste povezavo v brezžično omrežje nastavili kasneje.**



9. Izberite omrežno mesto.
Kliknite **Naprej** za nadaljevanje.
10. Postopek inicializacije je dokončan.



Namizje

Na namizju je več bližnjic. Če želite zagnati posamezno aplikacijo ali odpreti določeno mapo, dvokliknite na ustrezno bližnjico. Nekatere aplikacije ne morejo ustvarjati ikon v območju za obvestila.



Dejanski videz namizja se med posameznimi modeli lahko razlikuje.

Omrežna povezava

Konfiguracija povezave v brezžično omrežje

1. Kliknite na ikono omrežja z oranžno zvezdico v območju za obvestila Windows® .



Če se ikona brezžičnega omrežja z oranžno zvezdico ne prikaže v območju za obvestila, aktivirajte funkcijo brezžičnega LAN omrežja tako, da pred njegovo konfiguracijo pritisnete kombinacijo tipk




(**<Fn>** + **<F2>**).

2. Iz seznama izberite vstopno točko za brezžično omrežje v katerega se želite povezati, in kliknite **Vzpostavi povezavo**.



Če ne najdete želene vstopne točke, kliknite ikono **Osveži** v zgornjem desnem kotu in tako osvežite seznam ter poskusite točko znova poiskati.



3. Pri vzpostavljanju povezave boste morda morali vnesti geslo.
4. Ko boste vzpostavili povezavo, bo slednja prikazana na seznamu.
5. V območju za obvestila boste videli ikono brezžičnega omrežja .




Po pritisku **<Fn>** + **<F2>**, kar onemogoči funkcijo WLAN, se pojavi prekršana ikona brezžičnega omrežja .

Lokalno omrežje


Za povezavo s kabelskim omrežjem sledite spodnjim navodilom:

Uporaba omrežja z dinamičnim IP/PPPoE:


- Kliknite ikono omrežja z rumenim opozorilnim trikotnikom , ki je v območju za obvestila Windows® ter izberite **Odpri središče za omrežje in skupno rabo**.




- V modrem levem podoknu kliknite **Spreminjanje nastavitev kartice**.




- Desno kliknite **Povezava lokalnega omrežja** in izberite **Lastnosti**.



4. Kliknite **Različica internetnega protokola 4 (TCP/IP)**, nato kliknite **Lastnosti**.




5. Kliknite **Samodejno pridobi naslov IP** nato kliknite **V redu**.




(Nadaljujte z naslednjimi koraki, uporabite PPPoE)


6. Vrnite se na **Središče za omrežja in skupno rabo** nato kliknite **Nastavi novo povezavo ali omrežje**.




7. Izberite **Vzpostavitev povezave z internetom** in kliknite **Naprej**.




9. Vnesite svoje uporabniško ime in geslo ter ime povezave. Kliknite **Vzpostavi povezavo**.



11. Kliknite na omrežno ikono v vrstici z opravili in izberite pravkar ustvarjeno povezavo.



8. Izberite **Širokopasovno (PPPoE)** in kliknite **Naprej**.



10. Kliknite **Zapri** za dokončanje konfiguracije.




12. Vnesite svoje uporabniško ime in geslo. Kliknite **Vzpostavi povezavo** za vzpostavitev povezave z internetom.



Uporaba statičnega IP-ja:

1. Za konfiguracijo statičnega IP omrežja uporabite korake 1-4 za konfiguracijo dinamičnega IP.
2. Kliknite **Uporabi ta naslov IP**.
3. Vnesite IP naslov, masko podmrežja in omrežnega prehoda vašega ponudnika internetnih storitev.
4. Če je potrebno, vnesite naslov DNS in dodatni naslov.
5. Po vnosu vseh potrebnih vrednosti kliknite **V redu**, da vzpostavite omrežno povezavo.



Če imate težave s povezovanjem v omrežje, kontaktirajte vašega ponudnika internetnih storitev (ISP).

Brskanje po spletnih straneh

Ko dokončate nameščanje omrežja, kliknite ikono **Internet Explorer** na namizju in začnite z deskanjem po spletu.



Za najnovejše informacije in registracijo obiščite domačo stran Eee PC (<http://eepc.asus.com>) popolne storitve za vaš Eee PC pa so na voljo na <http://vip.asus.com>.

Posodobitev ASUS

Povezava Bluetooth (na izbranih modelih)

Super hibridni mehanizem

Eee Docking (na izbranih modelih)

Instant On (na izbranih modelih)

Opomba glede polnjenja zunanjih naprav prek vrat USB

Microsoft® Office Starter 2010

Uporaba Eee PC



Posodobitev ASUS

Posodobitev ASUS je orodje s katerim lahko upravljate, shranjujete in posodabljate BIOS Eee PC v okolju Windows®. Posodobitev ASUS vam omogoča tudi:

- Shranjevanje datoteke s trenutnimi nastavtvami BIOS-a
- Prenos najnovejše datoteke z nastavtvami BIOS z interneta
- Posodobitev BIOS-a s posodobljene datoteke BIOS
- Posodobitev BIOS-a neposredno z interneta
- Ogled informacij o trenutni različici BIOS-a.

To orodje je prednaloženo na vaš Eee PC.




Posodobitev ASUS deluje le, če je uspešno vzpostavljena internetna povezava, bodisi v omrežje ali preko ponudnika internetnih storitev (ISP).


Posodabljanje BIOS-a preko interneta

Posodabljanje BIOS-a preko interneta

1. Zaženite posodobitev ASUS sistema Windows®, tako da kliknete **Start > Vsi programi > ASUS > ASUSUpdate for Eee PC > ASUSUpdate**. Prikaže se glavno okno posodobitve ASUS.



2. S spustnega seznama izberite **Update BIOS from Internet (Posodobi BIOS z interneta)**, nato kliknite **Next (Naprej)**.



- Izberite najbližjo stran ASUS FTP, da si zagotovite najenostavnnejši prenos ali kliknite **Auto Select (Samodejna izbira)**. Kliknite **Next (Naprej)**.
- Na FTP strani izberite želeno različico BIOS-a in kliknite **Next (Naprej)**.
- Za zaključek postopka posodobitve sledite navodilom na zaslonu.




Orodje posodobitev ASUS se lahko samodejno posodablja preko interneta. Da orodje zares temeljito izkoristite, ga sproti posodabljaljajte.

Posodabljanje BIOS-a preko datoteke BIOS

Posodabljanje BIOS-a preko datoteke BIOS:

- Zaženite posodobitev ASUS sistema Windows®, tako, da kliknete **Start > Programi > ASUS > ASUSUpdate for Eee PC > ASUSUpdate**. Prikaže se glavno okno posodobitve ASUS.
- S spustnega seznama izberite **Update BIOS from file (Posodobi BIOS z datoteke)**, -nato kliknite **Next (Naprej)**.
- Izberite datoteko BIOS v oknu **Odpri**, nato kliknite **Odpri**.
- Za zaključek postopka posodobitve sledite navodilom na zaslonu.




Povezava Bluetooth (na izbranih modelih)

Tehnologija Bluetooth omogoča brezkabelsko povezavo z Bluetooth-omogočenimi napravami. Naprave z bluetooth tehnologijo so npr. prenosni računalnik, namizni računalniki, mobilniki in dlančniki.

Povezava z Bluetooth omogočeno napravo:

1. Zaporedoma pritiskajte **<Fn> + <F2>**, dokler se ne prikažeta **Bluetooth ON** ali **WLAN & Bluetooth ON**.


2. V Nadzorna plošča, pojrite na **Omrežje in internet > Središče za omrežje in skupno rabo**, nato v levem modrem podoknu kliknite **Spreminjanje nastavitev kartice**.




3. Desnokliknite na **Bluetooth omrežna povezava** ter izberite **Ogled omrežnih naprav bluetoot**.



4. Za ogled novih naprav, kliknite **Dodaj napravo**.
5. S seznama izberite bluetooth-omogočeno napravo in kliknite **Naprej**.



6. Vnesite varnostno kodo bluetooth in začnite s povezovanjem naprav.
7. Napravi sta se uspešno povezali. Za dokončanje nastavite kliknite **Zapri**.




Super hibridni mehanizem

Super hibridni mehanizem omogoča več načinov napajanja z energijo. Načini varčevanja z energijo nadzirajo mnogo vidikov vašega Eee PC, bodisi za najvišjo zmogljivost ali pa za podaljševanje trajanja baterije. Izbrani način je prikazan na zaslolu.

Za spremembo načina napajanja

- Kliknite **Start > Vsi programi > ASUS > EeePC > SuperHybridEngine > SuperHybridEngine.**
- Desnokliknite na ikono Super hibridni mehanizem v območju za obvestila in izberite želeni način napajanja.
- Za preklop med načini napajanja zaporedoma pritisnite kombinacijo tipk **<Fn> + <Space Bar>**.



Super hibridni mehanizem Modes (Načini super hibridnega mehanizma)



Power Saving



High Performance



Super Performance



Načina **Auto High Performance (Samodejno visoko-učinkovito)** in **Auto Power-Saving (samodejno varčevanje z energijo)** sta na voljo le, ko priklopite ali odklopite napajalni adapter.



Auto Power-Saving




Auto High-Performance



Če običajno uporabljate zunanj monitor na načinu **Power Saving (Varčevanje z energijo)** pri ločljivosti 1024 x 768 slikovnih pik ali večji, zaporedoma pritisnite **<Fn> + <F8>** in tako preklopite zaslons v način **Le LCD** ali **LCD + CRT klon** ter ponastavite način napajanja v **High Performance (Visoka učinkovitost)** ali **Super Performance (Super učinkovitost)**.

Eee Docking (na izbranih modelih)

Eee Docking nudi več uporabnih aplikacij. Orodna vrstica Eee Docking se nahaja na zgornjem delu namizja.



- Aplikacije v Eee Docking se med modeli lahko razlikujejo.
- Imena aplikacij v Eee Docking so predmet sprememb brez predhodnega opozorila.

Access

ASUS @Vibe

ASUS @Vibe vam omogoča prikaz zabavnih vsebin, kot so Radio, TV v živo in Igre, itd.



Vsebina storitve ASUS @Vibe se razlikuje med posameznimi območji.

Game Park

Game Park vam nudi različne zanimive igre.

ASUS WebStorage

Uporabniki Eee PC lahko uporabljajo brezplačna spletna mesta. Preko internetne povezave lahko dostopate do vsebin, in imate v skupni rabi datoteke kjerkoli in kadarkoli. Datoteka s pomočjo ASUS WebStorage je na voljo le, ko ste z Eee PC uspešno povezani v internet.

Sharing

Media Sharing (na izbranih modelih)

Program za Media Sharing ASUS omogoča, da predvajate glasbo, videoposnetke in diaprojekcije slik tako, da vsebine pošiljate na katero koli napravo, ki podpira DLNA. Predvajanje vsebin na združljivi napravi je preprosto. Izmed razpoložljivih strežnikov z vsebinami izberite svoj sistem, izberite vrsto večpredstavnosti, ki jo želite gledati in jo dodajte napravi.

YouCAM

YouCAM pri tem pa imate na voljo zanimive in uporabne učinke ter dodatke za spletno kamero.

Syncables

Aplikacija Syncables Desktop vam olajša sinhronizacijo ter posodabljanje fotografij, glasbe, video posnetkov, dokumentov, zaznamkov in še več na vseh vaših računalnikih.

Experience

Font Resizer

Font Resizer vam omogoča nastavljanje velikosti pisave na zaslonu vašega Eee PC.

Tools

Posodobitev v živo

Posodobitev v živo s stalnim preverjanjem spletnih posodobitev ohranja vaš Eee PC stalno posodobljen.

USB Charge+

Z USB Charge+ polnite mobilne telefone ali digitalne zvočne predvajalnike, medtem ko je računalnik Eee v stanju spanja, mirovanja ali pa je ugasnjena. Ta lastnost je privzeto onemogočena. Ko je omogočena, sta na voljo dva načina: Način adapter ali Način adapter + baterija.



USB Charge+ je onemogočen, ko je računalnik Eee prižgan, vrata USB pa se uporabljajo le za prenos podatkov.

LocaleMe

LocaleMe je spletna aplikacija, ki vam omogoča enostavno iskanje ulic ali naslovov, razvrščenih v različne kategorije, širokem svetu.



Locale Me za delovanje potrebuje povezavo z Internetom.

Docking Setting

Nastavitev združitve vam omogoča konfiguracijo videza in položaja orodne vrstive Eee Docking.

Instant On (na izbranih modelih)

Zagon sistema brez čakanja omogoča, da se takoj vrnete k delu in zabavi, tako da shrani stanje sistema. Ko takojšnji vklop aktivirate, se gumb ZAUSTAVITEV SISTEMA v meniju Start spremeni v SPANJE, tako da lahko lagodno uporabljate funkcijo obnovitev zadnjega delovnega stanja.



Med POSODOBITVIJO SISTEMA WINDOWS se funkcija »Instant On« samodejno onemogoči, tako da se gumb ZAUSTAVITEV SISTEMA ne spremeni v SPANJE, preden se vse posodobitve ne dokončajo.

Opomba glede polnjenja zunanjih naprav prek vrat USB

Z vrati USB lahko polnite mobilne naprave, ko je Eee PC vključen (uporabljate lahko vsa vrata USB 2.0/3.0), v stanju mirovanja, hibernacije ali ko je izključen (uporabljate lahko vrata USB 2.0, ki imajo omogočeno funkcijo USB Charge+). Če polnite naprave z veliko porabo energije, kot so tablične naprave, Eee PC vedno priključite na napajalni adapter AC in napravo izključite oz. jo preklopite v stanje hibernacije, da se polni.



Polnjenje preko vhoda USB lahko traja dlje.

Microsoft® Office Starter 2010

Uporabniki Eee PC lahko uporabljajo Microsoft Office Starter 2010, ki vključuje Word Starter 2010 in Excel Starter 2010 za osnovno obdelavo besedila in preglednice. Pri prvem zagonu Office Starter 2010 naredite naslednje:

1. Kliknite **Start > Vsi programi > Microsoft Office 2010**.
2. V oknu **Microsoft Office 2010** kliknite **Uporabi**.




3. Kliknite **Odpri** za nadaljevanje.



4. Eee PC začne nalagati programe Microsoft Office Starter 2010.



- KO so programi nameščeni, morate vnesti svoje polno ime in začetnice. Kliknite **V redu** za nadaljevanje.



- Preberite licenčno pogodbo Microsoft Office in kliknite **Sprejmem**, kar pomeni, da se strinjate.



- Izberite svoj najljubši način posodobitve Microsoft Office in za nadaljevanje kliknite **V redu**.



- Zdaj lahko začnete uporabljati Microsoft Excel Starter 2010 in Microsoft Word Starter 2010.



- Če želite v bodoče uporabljati ostale programe Microsoft Office Starter 2010, kliknite **Start > Vsi programi > Microsoft Office Starter**, da izberete želen program.
- Za aktivacijo ali nakup celotne različice Microsoft Office 2010, kliknite **Start > Vsi programi > Microsoft Office 2010**.

Obnovitev sistema

Obnovitev sistema 4

Obnovitev sistema



Pred uporabo F9 obnovitve priključite računalnik Eee na AC napajanje, da ne pride do napake pri obnavljanju.


Uporaba obnovitvene particije (F9 obnovitve)

1. Med zagonom pritisnite <F9>.




Pazite, da boste med zagonom tipko <F9> pritisnili le enkrat.

2. Izberite jezik, ki ga uporabljate, in kliknite → za nadaljevanje.



3. Za zagon obnovitve sistema kliknite pogovorno okno **Recovery System (Obnovitev Obnovitveni sistem).**



4. Sistem samodejno zažene postopek obnovitve, za njegovo dokončanje sledite navodilom na zaslonu.

Varnostno kopiranje datotek za obnovitev

1. Ponovite koraka 1–2 v prejšnjem razdelku.
2. Priključite shranjevalno napravo USB na svoj Eee PC in kliknite **Backup (Varnostno kopiranje)** v pogovornem oknu **Recovery System (Obnovitveni sistem)** za začetek varnostnega kopiranja obnovitvenih datotek.



- Velikost priključene shranjevalne naprave USB mora biti večja od 16 GB.
- Za to funkcijo pomnilniške kartice niso podprte.
- Priključite napravo za shranjevanje v vrata USB 2.0.
- Če na Eee PC niste priključili naprave za shranjevanje USB za varnostno kopiranje za sistemsko obnovitev, se pojavi pogovorno okno kot opomnik.



3. Izberite želeno napravo za shranjevanje USB, če je na Eee PC priključena več kot ena naprava USB in kliknite **Continue (Nadaljuj).**




4. Vsi podatki na izbrani napravi za shranjevanje USB bodo poчиščeni. Kliknite **Continue (Nadaljuj)** za začetek varnostnega kopiranja ali kliknite **Back (Nazaj)** za varnostno kopiranje pomembnih podatkov.



Izgubili boste vse podatke na izbrani napravi za shranjevanje USB. Prepričajte se, da imate varnostne kopije pomembnih podatkov

5. Varnostno kopiranje sistema se začne in ko konča, kliknite **OK (V redu).**





Uporaba naprave za shranjevanje USB (obnovitev USB)



Uporabite vrata USB 2.0 za varnostno kopiranje datotek prek USB.

- Priklučite napravo za shranjevanje USB, ki jo uporabljate za varnostno kopiranje datotek za sistemsko obnovitev.
- Med zaganjanjem pritisnite <ESC> in pojavit se bo zaslon **Please select boot device (Izberite zagonsko napravo)**. Izberite USB:XXXXXX za zagon iz priključene naprave za shranjevanje USB.
- Izberite jezik, ki ga uporabljate, in kliknite → za nadaljevanje.
- Kliknite **Recovery (Obnovitev)** za začetek obnovitve sistema.



- Izberite možnost particije in kliknite **Continue (Nadaljuj)**. Možnosti particije:
 - Recover system to a partition. (Obnovitev sistema na particijo.)**
Ta možnost izbriše vse podatke na vaši sistemski particiji "C" in ne spremeni particije "D".
 - Recover system to entire HD. (Obnovitev sistema na celoten trdi disk.)**
Ta možnost izbriše vse particije na vašem trdem disku in ustvari novo sistemsko particijo kot pogon "C" ter podatkovno particijo kot pogon "D".
- Za zaključek postopka obnovitve sledite navodilom na zaslonu.



Deklaracije in varnostne izjave
Informacije o avtorskih pravicah
Omejitev odgovornosti
Storitev in podpora

Dodatek

Deklaracije in varnostne izjave

IZJAVA FEDERAL ZVEZNE KOMISIJE ZA KOMUNIKACIJE

Ta naprava je bila testirana in izpolnjuje omejitve za digitalne naprave razreda B, v skladu s predpisi točke 15. pravilnika komisije za zvezne komunikacije (FCC). Te omejitve so določene za zagotovitev sprejemljive zaščite pred škodljivimi motnjami v stanovanjskih namestitvah. Ta oprema povzroča, uporablja in oddaja radijsko frekvenco in če ni pravilno nameščena in uporabljena v skladu z navodili, lahko povzroči škodljive motnje na radijskih sprejemnikih. Kljub temu ni garancije, da na določenih namestitvah ne bo prišlo do motenj. Če ta oprema povzroča škodljive motnje na radijskih ali televizijskih sprejemnikih, kar se da preveriti z vklopom in izklopom sprejemnikov, lahko uporabnik motenje popravi z enim ali več od navedenih ukrepov:

- Obrnite ali prestavite sprejemno anteno.
- Povečajte razdaljo med aparati in sprejemnikom.
- Priklopite aparat na vtičnico, ki ni ista na katero je priklopljen sprejemnik.
- Za pomoč se obrnite na izkušenega radijskega /TV tehnika.



Kakršne koli spremembe in predelave, ki niso izrecno dovoljene v garanciji te naprave, lahko preprečijo kupcu varno uporabo opreme.

Zahteve glede označevanja

Ta naprava je v skladu s 15. delom pravilnika FCC. Delovanje je pogojeno z dvema sledečima pogojema: (1) ta naprava ne povzroča škodljivih motenj, in (2) ta naprava mora sprejemati vsakršne motnje, vključno s takšnimi, ki bi lahko povzročile neželeno delovanje.

Opozorilo glede izpostavljenosti radijskim frekvencam

Oprema mora biti nameščena in mora delovati v skladu s priloženimi navodili in ne sme biti nameščena skupaj ali v povezavi z drugimi antenami ali oddajniki. Končni uporabniki in osebe, ki opremo nameščajo, morajo upoštevati skladnost radiofrekvenčne izpostavljenosti in morajo imeti navodila za namestitev antene in informacije glede delovnih pogojev oddajnika.

Izjava o skladnosti (R in TTE direktive 1999/5/EC)

Naslednji dokončani elementi se smatrajo kot ustreznih in zadostnih:

- Osnovne zahteve kot v [člen 3]
- Zahteve o zaščiti za zdravje in varnost kot v [člen 3,1a]
- Testiranje električne varnosti glede na [EN 60950]
- Zahteve po zaščiti elektromagnetne združljivosti v [člen 3,1b]
- Testiranje elektromagnetne združljivosti v [EN 301 489-1] in [EN 301]
- Testiranje v skladu z [489-17]
- Učinkovita uporaba radijskega spektra kot v [člen 3,2]
- Ustreznost radijskega testa glede na [EN 300 328-2]

Označitev CE opozorila



CE označevanje naprav brez brezžičnega LAN-a/aplikacije Bluetooth

Dobavljena različica te naprave je skladna z zahtevami direktiv EGS 2004/108/ES "elektromagnetna združljivost" in 2006/95/ES "direktiva o nizkih napetostih".



CE označevanje naprav z brezžičnim LAN-om/aplikacijo Bluetooth

Ta oprema je skladna z zahtevami Direktivo 1999/5/ES Evropskega parlamenta in Komisije z dne 9. marca 1999, ki ureja radijsko in telekomunikacijsko opremo ter vzajemno priznavanje skladnosti.

Brezžični operacijski kanal za različne domene

S. Amerika	2.412-2.462 GHz	Ch01 skozi CH11
Japonska	2.412-2.484 GHz	Ch01 skozi Ch14
Evropa ETSI	2.412-2.472 GHz	Ch01 skozi Ch13

Francija omejitev brezžičnega frekvenčnega pasu

Nekateri območja v Franciji imajo omejitev frekvenčnega pasu. V najslabšem primeru je maksimalna možna moč v notranjih prostorih:

- 10mW za ves 2,4 GHz pas (2400 MHz–2483,5 MHz)
- 100mW za frekvence med 2446,5 MHz in 2483,5 MHz



Kanali 10 skozi vključno 13 deluje v pasu 2446,6 MHz do 2483,5 MHz.

Obstaja nekaj možnosti za zunanjou uporabo: Na zasebnem posestvu ali zasebnem posestvu javnih oseb je uporaba možna s predhodnim postopkom odobritve s strani ministrstva za obrambo, z maksimalno odobreno močjo od 100mW v 2446,5–2483,5 MHz pasu. Zunanja uporaba na javnih površina ni dovoljena.

V spodaj naštetih departmajih za ves 2,4 GHz pas:

- Maksimalna odobrena moč v notranjih prostorih je 100mW
- Maksimalna odobrena moč zunaj je 10mW

Departamaji v katerih je odobrena moč pasu 2400–2483,5 MHz z EIRP ali manj kot 100mW v notranjih prostorih in manj kot 10mW zunaj:

01 Ain	02 Aisne	03 Allier
05 Hautes Alpes	08 Ardennes	09 Ariège
11 Aude	12 Aveyron	16 Charente
24 Dordogne	25 Doubs	26 Drôme
32 Gers	36 Indre	37 Indre et Loire
41 Loir et Cher	45 Loiret	50 Manche
55 Meuse	58 Nièvre	59 Nord
60 Oise	61 Orne	63 Puy du Dôme
64 Pyrénées Atlantique	66 Pyrénées Orientales	

67 Bas Rhin	68 Haut Rhin	70 Haute Saône
71 Saône et Loire	75 Paris	82 Tarn et Garonne
84 Vaucluse	88 Vosges	89 Yonne
90 Territoire de Belfort	94 Val de Marne	

Te zahteve se znajo čez čas spremeniti in vam omogočiti uporabo kartice brezžičnega LAN-a v več obmojih v Franciji. Prosimo preverite pri ART za zadnje informacije (www.arcep.fr).



Vaša WLAN kartica prenaša manj kot 100mW, vendar več kot 10mW.

UL varnostni napotki

Zahteve za UL 1459 pokritost telekomunikacijske naprave (telefon), ki naj bi bile priklopljene z elektriko na telekomunikacijsko omrežje, ki ima ozemljeno delovno napetost, ki ne presega vrha 200V, 300v od vrha do vrha in 105V rms in nameščeno ali uporabljeni v skladu z Nacionalnim elektro kodeksom (NFPA 70).

Pri uporabi modema Eee PC se morajo vedno upoštevati osnovni varnostni ukrepi za zmanjšanje tveganja z ognjem, električnim šokom in poškodb oseb, vključujuo sledeče:

- Ne uporabljajte Eee PC v bližini vode npr. blizu kadi, umivalnika, kuhinjskega korita ali pomivalnega korita, v vlažni kleti ali blizu bazena.
- Eee PC NE uporabljajte v času neviht. Zaradi strel obstaja manjša možnost električnega šoka.
- Ne uporabljajte Eee PC v bližini uhajanja plina.

Za vir energije v proizvodih so potrebne za UL 1642, ki obsegajo primarne (ne potrebujejo ponovnega polnjenja) in sekundarne (ponovno polnjenje) baterije z litijem. Te baterije vsebujejo kovinski litij ali primes litija, ali delni litij in so lahko sestavljene iz ene elektrokemične celice ali iz dveh ali več celic, ki so povezane v serije, vzporedne ali oboje, ki spremenijo kemično energijo v električno energijo z nespremenljivo ali spremenljivo kemično reakcijo.

- Ne mečite baterij iz Eee PC v ogenj, saj lahko eksplodirajo. Preverite lokalne predpise o posebnih navodilih za odstranitev, ki naj bi zmanjšala nevarnost poškodb oseb zaradi ognja ali eksplozije.
- Ne uporabite električnih dodatkov ali baterij iz ostalih naprav za zmanjšanje nevarnosti poškodb oseb zaradi ognja ali eksplozije. Uporabite le potrjene UL električne priključke ali baterije, ki jih dobite pri proizvajalcu ali pooblaščenih trgovcih.

Zahteve za varno napajanje

Proizvodi z električnim napajanje do 6A in s težo nad 3 kg morajo biti uporabljeni odobrene električne kable, ki so večji ali enaki kot: H05VV-F, 3G, 0,75 mm² or H05VV-F, 2G, 0,75mm².

REACH

Vsebnosti kemijskih snovi v naših izdelkih smo objavili skladno s predpisi REACH (Registracija, evalvacija, avtorizacija in omejevanje kemikalij) na ASUS REACH spletni strani na naslovu
<http://csr.asus.com/english/REACH.htm>.

Izdelek skladen z ENERGY STAR



ENERGY STAR je skupni program Agencije ZDA za varstvo okolja in Oddelka za energijo ZDA, ki nam vsem pomaga prihraniti denar in zaščititi okolje s pomočjo energetsko učinkovitih izdelkov in praks.

Vsi izdelki ASUS z logotipom ENERGY STAR so v skladu s standardom ENERGY STAR, lastnost upravljanja z energijo pa je omogočena privzeto.

Monitor in računalnik se samodejno preklopita v način mirovanja po 15 in 30 minutah nedejavnosti. Če računalnik želite zbuditi, kliknite z miško ali pritisnite katero koli tipko na tipkovnici.

Za podrobne informacije o upravljanju z energijo in koristi za okolje obiščite <http://www.energy.gov/powermanagement>. Poleg tega obiščite tudi <http://www.energystar.gov>, kjer boste našli podrobne podatke o skupnem programu ENERGY STAR.

OPOMBA: Energy Star ni podprt na izdelkih s sistemom Freedos in Linux.

Skladnost z globalnimi okoljskimi predpisi in izjava

ASUS pri oblikovanju in izdelavi svojih izdelkov sledi ekološkemu konceptu in zagotavlja, da je vsak cikel življenjske dobe izdelka ASUS usklajen z globalnimi okoljskimi predpisi. Poleg tega ASUS razkriva pomembne informacije, ki temeljijo na zahtevah predpisov.

Za razkritje informacij, ki temeljijo na zahtevah predpisov, s katerimi je ASUS usklajen, glejte <http://csr.asus.com/english/Compliance.htm>:

- Japan JIS-C-0950 Material Declarations
- EU REACH SVHC
- Korea RoHS
- Swiss Energy Laws

Recikliranje ASUS/Storitve vračanja

ASUS-ovi programi recikliranja in vračanja izhajajo iz naše predanosti najvišnjim standardom za zaščito okolja. Verjamemo v rešitve za naše stranke, s čimer bodo lahko odgovorno reciklirale naše izdelke, baterije in druge sestavne dele ter pakirni material. Za podrobnejše informacije o recikliraju v različnih regijah obiščite <http://csr.asus.com/english/Takeback.htm>.

Nordijska opozorila za litij (za baterije z delnim litijem)



CAUTION! Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions.
(English)



ATTENZIONE! Rischio di esplosione della batteria se sostituita in modo errato. Sostituire la batteria con un una di tipo uguale o equivalente consigliata dalla fabbrica. Non disperdere le batterie nell'ambiente. (Italian)



VORSICHT! Explosionsgefahr bei unsachgemäßen Austausch der Batterie. Ersatz nur durch denselben oder einem vom Hersteller empfohlenem ähnlichen Typ. Entsorgung gebrauchter Batterien nach Angaben des Herstellers. (German)



ADVARSEL! Lithiumbatteri - Eksplorationsfare ved fejlagtig håndtering. Udkiftning må kun ske med batteri af samme fabrikat og type. Levér det brugte batteri tilbage til leverandøren. (Danish)



VARNING! Explosionsfara vid felaktigt batteribyte. Använd samma batterityp eller en ekvivalent typ som rekommenderas av apparattillverkaren. Kassera använd batteri enligt fabrikantens instruktion. (Swedish)



VAROITUS! Paristo voi räjähtää, jos se on virheellisesti asennettu. Vaihda paristo ainoastaan laitevalmistajan sotisittelemaan tyyppiin. Hävitä käytetty paristo valmistagan ohjeiden mukaisesti. (Finnish)



ATTENTION! Il y a danger d'explosion s'il y a remplacement incorrect de la batterie. Remplacer uniquement avec une batterie du même type ou d'un type équivalent recommandé par le constructeur. Mettre au rebut les batteries usagées conformément aux instructions du fabricant. (French)



ADVARSEL! Ekspløsjonsfare ved feilaktig skifte av batteri. Benytt samme batteritype eller en tilsvarende type anbefalt av apparatfabrikanten. Brukte batterier kasseres i henhold til fabrikantens instruksjoner. (Norwegian)



標準品以外の使用は、危険の元になります。交換品を使用する場合、製造者に指定されるものを使って下さい。製造者の指示に従って処理して下さい。 (Japanese)



ВНИМАНИЕ! При замене аккумулятора на аккумулятор иного типа возможно его возгорание. Утилизируйте аккумулятор в соответствии с инструкциями производителя. (Russian)

Offer to Provide Source Code of Certain Software

This product contains copyrighted software that is licensed under the General Public License ("GPL") and under the Lesser General Public License Version ("LGPL"). The GPL and LGPL licensed code in this product is distributed without any warranty. Copies of these licenses are included in this document.

You may obtain the complete corresponding source code (as defined in the GPL) for the GPL Software, and/or the complete corresponding source code of the LGPL Software (with the complete machine-readable "work that uses the Library") for a period of three years after our last shipment of the product including the GPL Software and/or LGPL Software, which will be no earlier than December 1, 2011, either

- (1) for free by downloading it from <http://support.asus.com/download> ;
or

(2) for the cost of reproduction and shipment, which is dependent on the preferred carrier and the location where you want to have it shipped to, by sending a request to:

ASUSTeK Computer Inc.
Legal Compliance Dept.
15 Li Te Rd., Beitou, Taipei 112
Taiwan

In your request please provide the name, model number and version, as stated in the About Box of the product for which you wish to obtain the corresponding source code and your contact details so that we can coordinate the terms and cost of shipment with you.

The source code will be distributed WITHOUT ANY WARRANTY and licensed under the same license as the corresponding binary/object code.

This offer is valid to anyone in receipt of this information.

ASUSTeK is eager to duly provide complete source code as required under various Free Open Source Software licenses. If however you encounter any problems in obtaining the source code in the manner described or if there are any parts missing in the source code provided, we would be much obliged if you give us a notification to the email address gpl@asus.com, stating the product and describing the problem(please do NOT send large attachments such as source code archives etc to this email address).

GNU GENERAL PUBLIC LICENSE

Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc.,
51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA
Everyone is permitted to copy and distribute verbatim copies
of this license document, but changing it is not allowed.

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Lesser General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

GNU GENERAL PUBLIC LICENSE

TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law; that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.

b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.

c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,

b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,

c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically

terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances. It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. END OF TERMS AND CONDITIONS

How to Apply These Terms to Your New Programs

If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms.

To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the "copyright" line and a pointer to where the full notice is found.

<one line to give the program's name and a brief idea of what it does.>

Copyright (C) <year> <name of author>

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA.

Also add information on how to contact you by electronic and paper mail.

If the program is interactive, make it output a short notice like this when it starts in an interactive mode:

Gnomovision version 69, Copyright (C) year name of author Gnomovision comes with ABSOLUTELY NO WARRANTY; for details type 'show w'. This is free software, and you are welcome to redistribute it under certain conditions; type 'show c' for details.

The hypothetical commands 'show w' and 'show c' should show the appropriate parts of the General Public License. Of course, the commands you use may be called something other than 'show w' and 'show c'; they could even be mouse-clicks or menu items--whatever suits your program.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the program, if necessary. Here is a sample; alter the names:

Yoodyne, Inc., hereby disclaims all copyright interest in the program 'Gnomovision'
(which makes passes at compilers) written by James Hacker.

<signature of Ty Coon>, 1 April 1989

Ty Coon, President of Vice

This General Public License does not permit incorporating your program into proprietary programs. If your program is a subroutine library, you may consider it more useful to permit linking proprietary applications with the library. If this is what you want to do, use the GNU Lesser General Public License instead of this License.

GNU LESSER GENERAL PUBLIC LICENSE

Version 2.1, February 1999

Copyright (C) 1991, 1999 Free Software Foundation, Inc.

51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA

Everyone is permitted to copy and distribute verbatim copies of this license document,
but changing it is not allowed.

[This is the first released version of the Lesser GPL. It also counts as the successor of the GNU Library Public
License, version 2, hence the version number 2.1.]

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public Licenses are intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users.

This license, the Lesser General Public License, applies to some specially designated software packages--typically libraries--of the Free Software Foundation and other authors who decide to use it. You can use it too, but we suggest you first think carefully about whether this license or the ordinary General Public License is the better strategy to use in any particular case, based on the explanations below.

When we speak of free software, we are referring to freedom of use, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish); that you receive source code or can get it if you want it; that you can change the software and use pieces of it to new free programs; and that you are informed that you can do these things.

To protect your rights, we need to make restrictions that forbid distributors to deny you these rights or to ask you to surrender these rights. These restrictions translate to certain responsibilities for you if you distribute copies of the library or if you modify it.

For example, if you distribute copies of the library, whether gratis or for a fee, you must give the recipients all the rights that we gave you. You must make sure that they, too, receive or can get the source code. If you link other code with the library, you must provide complete object files to the recipients, so that they can relink them with the library after making changes to the library and recompiling it. And you must show them these terms so they know their rights.

We protect your rights with a two-step method: (1) we copyright the library, and (2) we offer you this license, which gives you legal permission to copy, distribute and/or modify the library.

To protect each distributor, we want to make it very clear that there is no warranty for the free library. Also, if the library is modified by someone else and passed on, the recipients should know that what they have is not the original version, so that the original author's reputation will not be affected by problems that might be introduced by others.

Finally, software patents pose a constant threat to the existence of any free program. We wish to make sure that a company cannot effectively restrict the users of a free program by obtaining a restrictive license from a patent holder. Therefore, we insist that any patent license obtained for a version of the library must be consistent with the full freedom of use specified in this license.

Most GNU software, including some libraries, is covered by the ordinary GNU General Public License. This license, the GNU Lesser General Public License, applies to certain designated libraries, and is quite different from the ordinary General Public License. We use this license for certain libraries in order to permit linking those libraries into non-free programs.

When a program is linked with a library, whether statically or using a shared library, the combination of the two is legally speaking a combined work, a derivative of the original library. The ordinary General Public License therefore permits such linking only if the entire combination fits its criteria of freedom. The Lesser General Public License permits more lax criteria for linking other code with the library.

We call this license the "Lesser" General Public License because it does less to protect the user's freedom than the ordinary General Public License. It also provides other free software developers less of an advantage over competing non-free programs. These disadvantages are the reason we use the ordinary General Public License for many libraries. However, the Lesser license provides advantages in certain special circumstances.

For example, on rare occasions, there may be a special need to encourage the widest possible use of a certain library, so that it becomes a de-facto standard. To achieve this, non-free programs must be allowed to use the library. A more frequent case is that a free library does the same job as widely used non-free libraries. In this case, there is little to gain by limiting the free library to free software only, so we use the Lesser General Public License.

In other cases, permission to use a particular library in non-free programs enables a greater number of people to use a large body of free software. For example, permission to use the GNU C Library in non-free programs enables many more people to use the whole GNU operating system, as well as its variant, the GNU/Linux operating system.

Although the Lesser General Public License is less protective of the users' freedom, it does ensure that the user of a program that is linked with the library has the freedom and the wherewithal to run that program using a modified version of the library.

The precise terms and conditions for copying, distribution and modification follow. Pay close attention to the difference between a "work based on the library" and a "work that uses the library". The former contains code derived from the library, whereas the latter must be combined with the library in order to run.

GNU LESSER GENERAL PUBLIC LICENSE

TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License Agreement applies to any software library or other program which contains a notice placed by the copyright holder or other authorized party saying it may be distributed under the terms of this Lesser General Public License (also called "this License"). Each licensee is addressed as "you".

A "library" means a collection of software functions and/or data prepared so as to be conveniently linked with application programs (which use some of those functions and data) to form executables.

The "Library", below, refers to any such software library or work which has been distributed under these terms. A "work based on the Library" means either the Library or any derivative work under copyright law: that is to say, a work containing the Library or a portion of it, either verbatim or with modifications and/or translated straightforwardly into another language. (Hereinafter, translation is included without limitation in the term "modification".)

"Source code" for a work means the preferred form of the work for making modifications to it. For a library, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the library.

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running a program using the Library is not restricted, and output from such a program is covered only if its contents constitute a work based on the Library (independent of the use of the Library in a tool for writing it). Whether that is true depends on what the Library does and what the program that uses the Library does.

1. You may copy and distribute verbatim copies of the Library's complete source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and distribute a copy of this License along with the Library.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Library or any portion of it, thus forming a work based on the Library, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

a) The modified work must itself be a software library.

b) You must cause the files modified to carry prominent notices stating that you changed the files and the date of any change.

c) You must cause the whole of the work to be licensed at no charge to all third parties under the terms of this License.

d) If a facility in the modified Library refers to a function or a table of data to be supplied by an application program that uses the facility, other than as an argument passed when the facility is invoked, then you must make a good faith effort to ensure that, in the event an application does not supply such function or table, the facility still operates, and performs whatever part of its purpose remains meaningful.

(For example, a function in a library to compute square roots has a purpose that is entirely well-defined independent of the application. Therefore, Subsection 2d requires that any application-supplied function or table used by this function must be optional: if the application does not supply it, the square root function must still compute square roots.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Library, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Library, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Library.

In addition, mere aggregation of another work not based on the Library with the Library (or with a work based on the Library) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may opt to apply the terms of the ordinary GNU General Public License instead of this License to a given copy of the Library. To do this, you must alter all the notices that refer to this License, so that they refer to the ordinary GNU General Public License, version 2, instead of to this License. (If a newer version than version 2 of the ordinary GNU General Public License has appeared, then you can specify that version instead if you wish.) Do not make any other change in these notices.

Once this change is made in a given copy, it is irreversible for that copy, so the ordinary GNU General Public License applies to all subsequent copies and derivative works made from that copy.

This option is useful when you wish to copy part of the code of the Library into a program that is not a library.

4. You may copy and distribute the Library (or a portion or derivative of it, under Section 2) in object code or executable form under the terms of sections 1 and 2 above provided that you accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange.

If distribution of object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place satisfies the requirement to distribute the source code, even though third parties are not compelled to copy the source along with the object code.

5. A program that contains no derivative of any portion of the Library, but is designed to work with the Library by being compiled or linked with it, is called a "work that uses the Library". Such a work, in isolation, is not a derivative work of the Library, and therefore falls outside the scope of this License.

However, linking a "work that uses the Library" with the Library creates an executable that is a derivative of the Library (because it contains portions of the Library), rather than a "work that uses the library". The executable is therefore covered by this License. Section 6 states terms for distribution of such executables.

When a "work that uses the Library" uses material from a header file that is part of the Library, the object code for the work may be a derivative work of the Library even though the source code is not. Whether this is true is especially significant if the work can be linked without the Library, or if the work is itself a library. The threshold for this to be true is not precisely defined by law.

If such an object file uses only numerical parameters, data structure layouts and accessors, and small macros and small inline functions (ten lines or less in length), then the use of the object file is unrestricted, regardless of whether it is legally a derivative work. (Executables containing this object code plus portions of the Library will still fall under Section 6.)

Otherwise, if the work is a derivative of the Library, you may distribute the object code for the work under the terms of Section 6. Any executables containing that work also fall under Section 6, whether or not they are linked directly with the Library itself.

6. As an exception to the Sections above, you may also combine or link a "work that uses the Library" with the Library to produce a work containing portions of the Library, and distribute that work under terms of your choice, provided that the terms permit modification of the work for the customer's own use and reverse engineering for debugging such modifications.

You must give prominent notice with each copy of the work that the Library is used in it and that the Library and its use are covered by this License. You must supply a copy of this License. If the work during execution displays copyright notices, you must include the copyright notice for the Library among them, as well as a reference directing the user to the copy of this License. Also, you must do one of these things:

a) Accompany the work with the complete corresponding machine-readable source code for the Library including whatever changes were used in the work (which must be distributed under Sections 1 and 2 above); and, if the work is an executable linked with the Library, with the complete machine-readable "work that uses the Library", as object code and/or source code, so that the user can modify the Library and then relink to produce a modified executable containing the modified Library. (It is understood that the user who changes the contents of definitions files in the Library will not necessarily be able to recompile the application to use the modified definitions.)

b) Use a suitable shared library mechanism for linking with the Library. A suitable mechanism is one that (1) uses at run time a copy of the library already present on the user's computer system, rather than copying library functions into the executable, and (2) will operate properly with a modified version of the library, if the user installs one, as long as the modified version is interface-compatible with the version that the work was made with.

c) Accompany the work with a written offer, valid for at least three years, to give the same user the materials specified in Subsection 6a, above, for a charge no more than the cost of performing this distribution.

d) If distribution of the work is made by offering access to copy from a designated place, offer equivalent access to copy the above specified materials from the same place.

e) Verify that the user has already received a copy of these materials or that you have already sent this user a copy.

For an executable, the required form of the "work that uses the Library" must include any data and utility programs needed for reproducing the executable from it. However, as a special exception, the materials to be distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

It may happen that this requirement contradicts the license restrictions of other proprietary libraries that do not normally accompany the operating system. Such a contradiction means you cannot use both them and the Library together in an executable that you distribute.

7. You may place library facilities that are a work based on the Library side-by-side in a single library together with other library facilities not covered by this License, and distribute such a combined library, provided that the separate distribution of the work based on the Library and of the other library facilities is otherwise permitted, and provided that you do these two things:

a) Accompany the combined library with a copy of the same work based on the Library, uncombined with any other library facilities. This must be distributed under the terms of the Sections above.

b) Give prominent notice with the combined library of the fact that part of it is a work based on the Library, and explaining where to find the accompanying uncombined form of the same work.

8. You may not copy, modify, sublicense, link with, or distribute the Library except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense, link with, or distribute the Library is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

9. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Library or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Library (or any work based on the Library), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Library or works based on it.

10. Each time you redistribute the Library (or any work based on the Library), the recipient automatically receives a license from the original licensor to copy, distribute, link with or modify the Library subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein.

11. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Library at all. For example, if a patent license would not permit royalty-free redistribution of the Library by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Library.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply, and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

12. If the distribution and/or use of the Library is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Library under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

13. The Free Software Foundation may publish revised and/or new versions of the Lesser General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Library specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Library does not specify a license version number, you may choose any version ever published by the Free Software Foundation.

14. If you wish to incorporate parts of the Library into other free programs whose distribution conditions are incompatible with these, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

15. BECAUSE THE LIBRARY IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE LIBRARY, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE LIBRARY "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE LIBRARY IS WITH YOU. SHOULD THE LIBRARY PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

16. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE LIBRARY AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE LIBRARY (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE LIBRARY TO OPERATE WITH ANY OTHER SOFTWARE), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

How to Apply These Terms to Your New Libraries

If you develop a new library, and you want it to be of the greatest possible use to the public, we recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

To apply these terms, attach the following notices to the library. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the "copyright" line and a pointer to where the full notice is found.

<one line to give the library's name and a brief idea of what it does.>

Copyright (C) <year> <name of author>

This library is free software; you can redistribute it and/or modify it under the terms of the GNU Lesser General Public License as published by the Free Software Foundation; either version 2.1 of the License, or (at your option) any later version.

This library is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU Lesser General Public License for more details.

You should have received a copy of the GNU Lesser General Public License along with this library; if not, write to the Free Software Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA

Also add information on how to contact you by electronic and paper mail.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the library, if necessary. Here is a sample; alter the names:

Yoyodyne, Inc., hereby disclaims all copyright interest in the library 'Frob'

(a library for tweaking knobs)written by James Random Hacker.

<signature of Ty Coon>, 1 April 1990 Ty Coon, President of Vice

That's all there is to it!

Informacije o avtorskih pravicah

Nobeno od teh navodil, vključno s proizvodi in programi, ki so tu opisani, ne sme biti kopirano, preneseno, prepisano, shranjeno v nadomestnih sistemih ali prevedeno v katerikoli jezik, v kakršnikoli obliki ali z drugimi sredstvi, razen dokumentacije shranjene s strani kupca v namene izdelave varnostne kopije, brez posebnega pisnega dovoljenja ASUSTek COMPUTER INC. ("ASUS").

ASUS PREDSTAVLJA TA NAVODILA "KOT SO" BREZ KAKRŠNEKOLI GARANCIJE, BODISI IZRAŽENE ALI VNEŠENE, VKLJUČNO VENDAR NE OMEJENO NA VNEŠENE GARANCIJE ALI POGOJEV PRODAJE ALI PRIPRAVLJENOSTI ZA DOLOČENE NAMENE. V NOBENEM PRIMERU NE BO ASUSU, NJEGOVI DIREKTORJI, USLUŽBENCI, ZAPOSLENI ALI PRODAJALCI ODGOVORNI ZA KAKRŠNEKOLI NEPOSREDNE, POSEBNE, SUČAJNE ALI POSLEDIČNE POŠKODBE (VKLJUČNO Z POSLEDICAMI ZARADI IZGUBE DOBITKA, IZGUBE POSLOVANJA, IZGUBE UPORABNOSTI ALI PODATKOV, PREKINITVIJO POSLOVANJA IN PODOBNO), TUDI ČE JE BIL ASUSU SVETOVANO O MOŽNOSTIH TOVRSTNIH POŠKODB, DO KATERIH JE PRIŠLO ZARADI OKVARE ALI NAPAKE V TEM NAVODILU ALI NA PROIZVODU.

Proizvodi in imena podjetij, ki se pojavljajo v teh navodilih so ali pa niso registrirane blagovne znamke ali avtorsko zaščitene s strani svojih podjetij in se uporabljajo le za poimenovanje ali razlago in v korist lastnika, brez potrebe po krštvah.

PODROBNOSTI IN INFORMACIJE, KI JIH NAVODILA VSEBUJEJO SO DANE LE V NAMENE INFORMIRANJA IN SE LAHKO SPREMENIJO KADARKOLI BREZ OPORIZILA IN NISO DEL OBVEZE S STRANI ASUS-A. ASUS NE NOSI NOBENE ODGOVORNOSTI ALI OBVEZE ZA KAKRŠNEKOLI NAPAKE ALI NEPRAVILNOSTRI, KI SE LAHKO POJAVIJO V TEH NAVODILIH, VKLJUČNO S PROIZVODI IN OPISANIMI PROGRAMI.

Copyright © 2011 ASUSTeK COMPUTER INC. Vse pravice pridržane.

Omejitev odgovornosti

Zaradi napake s strani ASUS-a ali koga drugega, se pojavi priložnosti pri kateri ste upravičeni do povrnitve škode s strani ASUS-a. V takem primeru, ne glede na to, da ste upravičeni do povrnitve škode s strani ASUS-a, je ASUS odgovoren le za poškodbe na telesu (vključno s smrtjo) in poškodbe na premoženju in na osebnem premoženju, ali kakšne druge dejanske ali neposredne poškodbe, ki so rezultat izogibanja ali neuspešne izvedbe pravnih dolžnosti v okviru garancije, v vrednosti zapisane pogodbene cene vsakega izdelka.

ASUS nosi odgovornost samo za nadomestitev vaše škode, poškodb ali zahtevka v pogodbi, postopka ali prekrška v okviru garancije.

Ta omejitev se nanaša tudi na dobavitelje in prodajalce ASUS-a. To je maksimalna kolektivna odgovornost ASUSA, njihovih dobaviteljev in prodajalcev.

ASUS NI POD NOBENIM POGOJEM ODGOVOREN ZA SLEDEČE: (1) ZAHTEVEK TRETJE OSEBE ZA POŠKODBE PROTI VAM; (2) IZGUBA ALI POŠKODBA NA VAŠIH ZAPISIH ALI PODATKIH; ALI (3) POSEBNA, NENAMERNA ALI NEPOSREDNA ŠKODA, ALI KAKRŠNAKOLI POSLEDIČNA POSLOVNA ŠKODA (VKLJUČNO Z IZGUBLJENIM DOBIČKOM ALI PRIHRANKI), TUDI ČE JE ASUSU, NJEGOVI DOBAVITELJI ALI NJIHOV PRODAJALEC O TEJ MOŽNOSTI OBVEŠČEN.

Storitev in podpora

Obiščite več jezikovno internet stran <http://www.asus.com>

Proizvajalec	ASUSTek COMPUTER INC.
Naslov, mesto	No. 150, LI-TE RD., PEITOU, TAIPEI 112, TAIWAN R.O.C
Država	TAIWAN
Pooblaščeni predstavnik v Evropi	ASUS COMPUTER GmbH
Naslov, mesto	HARKORT STR. 21-23, 40880 RATINGEN
Država	GERMANY