





# 10/100/1000Mbps Gigabit Ethernet Switch



## GX-D1051



## GX-D1081

### Quick Start Guide

#### Placement options



- DO NOT place any device on top of the switch.
- Leave enough space around the switch for adequate ventilation. Ensure that the switch is placed in a location that meets the environmental specifications.

#### Desktop placement


Put the switch on a flat and stable surface.

#### Wall mounting

Mount the switch on a wall with the mounting screws.

To mount the switch on a wall:


1. Secure the two screws into the wall.
2. Latch the hooks of the switch onto the screws.




- Use only the bundled AC adapter and power cord. Use of other power adapters may damage the device.
- If the AC adapter or power cord is damaged, return it to the dealer where it was purchased.
- The screws are not contained in the package.

# Connecting Devices to Your Switch

## 1. Connect your devices.



## 2. Check the LED indicators for the status of the switch and the network.



**EC Declaration of Conformity**

Manufacturer: ASUSTeK COMPUTER INC.  
 Address: No. 150, LI-TE RD., PEITOU, TAIPEI 112, TAIWAN R.O.C.  
 Country: TAIWAN  
 Authorized representative in Europe: ASUSTeK COMPUTER GmbH  
 Address: HARKORT STR. 21-23, 40880 RATINGEN  
 Country: GERMANY

Product name: 8 port Gigabit Desktop Switch  
 Model name: GX-D1051

conforms with the essential requirements of the following directives:

**EMC Directive**  
 EN 55024:2008/EN 55022:2008  
 EN 55024:2008/A1:2009/EN 55022:2008/A1:2009

**CE marking**  
 CE (EC conformity marking)  
 Position: CEO  
 Name: Jerry Shen  
 Declaration Date: Jan. 15, 2013  
 Year to begin affixing CE marking: 2011

**EC Declaration of Conformity**

Manufacturer: ASUSTeK COMPUTER INC.  
 Address: No. 150, LI-TE RD., PEITOU, TAIPEI 112, TAIWAN R.O.C.  
 Country: TAIWAN  
 Authorized representative in Europe: ASUSTeK COMPUTER GmbH  
 Address: HARKORT STR. 21-23, 40880 RATINGEN  
 Country: GERMANY

Product name: 8 port Gigabit Desktop Switch  
 Model name: GX-D1081

conforms with the essential requirements of the following directives:

**EMC Directive**  
 EN 55024:2008/EN 55022:2008  
 EN 55024:2008/A1:2009/EN 55022:2008/A1:2009

**CE marking**  
 CE (EC conformity marking)  
 Position: CEO  
 Name: Jerry Shen  
 Declaration Date: Jan. 15, 2013  
 Year to begin affixing CE marking: 2011

#### English

1. Connect your devices.
2. Check the LED indicators for the status of the switch and the network.

#### Русский

1. Подключите ваши устройства.
2. Проверьте индикаторы состояния коммутатора и сети.

#### Deutsch

1. Schließen Sie Ihre Geräte an.
2. Überprüfen Sie die LED-Anzeigen auf den Status des Switchs und des Netzwerks.

#### Italiano

1. Collegare le periferiche.
2. Controllare gli indicatori a LED per verificare lo stato dello switch e della rete.

#### Lietuvių

1. Prijunkite prietaisus.
2. Patikrinkite šviesinius indikatorius (LED), jei reikia informacijos apie perjungiklio ar tinklo būseną.

#### Latviski

1. Savienojiet savas ierices.
2. Pārbaudiet LED indikatorus komutatora un tīkla statusa noteikšanai.

#### Português

1. Ligue os dispositivos.
2. Verifique o estado do computador e da rede através dos LEDs indicadores.

#### Română

1. Conectați dispozitivele dvs.
2. Verificați indicatorii LED pentru starea comutatorului și a rețelei.

#### Polski

1. Podłącz swoje urządzenia.
2. Sprawdzić diody wskaźnikowe statusu przełącznika i sieci.

#### Español

1. Conecte sus dispositivos.
2. Consulte los indicadores LED si desea conocer el estado del concentrador y la red.

#### Українська

1. Підключіть пристрої.
2. Світлодіодні індикатори показують статус перемикача і мережі.

#### Français

1. Connectez les périphériques.
2. Vérifiez les indicateurs LED pour connaître l'état du switch et du réseau.

#### Português do Brasil

1. Conecte seus dispositivos.
2. Verifique os indicadores LED para ver o estado do interruptor e a rede.

#### Magyar

1. Csatlakoztassa az eszközöket.
2. Ellenőrizze a LED kijelzőket a switch és a hálózat állapotának megállapításához.

#### Slovensky

1. Pripojte svoje zariadenia.
2. Pomocou kontroly LED indikátorov skontrolujte stav prepínača a siete.

#### Česky

1. Pripojte zařízení.
2. Podle indikátorů LED lze kontrolovat stav prepínače a sítě.

#### Suomi

1. Kytke laitteet.
2. Tarkista LED-merkkivaloista kytkimen ja verkon tila.

#### Nederlands

1. Sluit uw apparaten aan.
2. Controleer de LED-indicatoren voor de status van de schakelaar en het netwerk.

#### Български

1. Свържете устройствата.
2. Проверете индикаторите за статуса на свича и мрежата.

#### Ελληνικά

1. Συνδέστε τις συσκευές σας.
2. Ελέγξτε τις ενδείξεις των λυχνιών LED για την κατάσταση του μεταγωγέα και του δικτύου.

#### Bahasa Indonesia

1. Sambungkan perangkat.
2. Periksa status switch dan jaringan pada indikator LED.

#### ไทย

1. เชื่อมต่ออุปกรณ์ของคุณ
2. ตรวจสอบว่าไฟแสดงสถานะ LED สำหรับสวิตช์และเครือข่าย

#### Türkçe

1. Aygıtlarınızı bağlayın.
2. Sviç ve ağız durumu için LED göstergelerini kontrol edin.

#### Eesti

1. Ühendage seadmed.
2. Kontrollige kommutaatori ja võrgu olekut väljendavaid LED indikaatoreid.

#### Bahasa Malaysia

1. Sambungkan peranti anda.
2. Periksa penunjuk LED untuk status suis dan rangkaian.

#### 简体中文

1. 连接设备。
2. 检查交换机与网络的 LED 状态指示灯。

#### 繁體中文

1. 連接裝置。
2. 檢查交換器與網路的 LED 狀態指示燈。

## Federal Communications Commission Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy, and if it is not installed and used in accordance with the instruction manual, it may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense.

## CE Mark Warning

This is a Class B product, in a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.

## REACH

Complying with the REACH (Registration, Evaluation, Authorisation, and Restriction of Chemicals) regulatory framework, we published the chemical substances in our products at ASUS REACH website at <http://green.asus.com/english/REACH.htm>.

## ASUS Recycling/Takeback Services

ASUS recycling and takeback programs come from our commitment to the highest standards for protecting our environment. We believe in providing solutions for you to be able to responsibly recycle our products, batteries, other components as well as the packaging materials. Please go to <http://csr.asus.com/english/Takeback.htm> for the detailed recycling information in different regions.

## ASUS Technical Support information

### ASUSTeK COMPUTER INC. (Asia Pacific)

Address: 15 Li-Te Road, Peitou, Taipei, Taiwan 11259  
Website: [www.asus.com.tw](http://www.asus.com.tw)

### Technical Support

Telephone: +886228943447  
Support Fax: +886228907698  
Software download: [support.asus.com\\*](http://support.asus.com)

### ASUS COMPUTER INTERNATIONAL (America)

Address: 800 Corporate Way, Fremont, CA 94539, USA  
Telephone: +15029550883  
Fax: +15029338713  
Website: [usa.asus.com](http://usa.asus.com)  
Software download: [support.asus.com\\*](http://support.asus.com)

### ASUS COMPUTER GmbH (Germany and Austria)

Address: Harkort Str. 21-23, D-40880 Ratingen, Germany  
Fax: +492102959911  
Website: [www.asus.com.de](http://www.asus.com.de)  
Online contact: [www.asus.com.de/sales](http://www.asus.com.de/sales)

### Technical Support

Telephone (Component): +491805010923  
Telephone (System/Notebook/Eee/LCD): +491805010920  
Fax: +492102959911  
Online support: [support.asus.com\\*](http://support.asus.com)

\* Available on this site is an online Technical Inquiry Form that you can fill out to contact technical support.

## Manufacturer

ASUSTeK Computer Inc.  
Tel: +886-2-2894-3447  
Address: No. 150, LI-TE RD., PEITOU, TAIPEI 112, TAIWAN

## Authorised representative in Europe

ASUS Computer GmbH  
Address: HARKORT STR. 21-23, 40880 RATINGEN, GERMANY

## Authorised distributors in Turkey

BOGAZICI BIL GISAYAR SAN. VE TIC. A.S.  
Tel: +90 212 3311000  
Address: AYAZAGA MAH. KEMERBURGAZ CAD. NO.10 AYAZAGA/ISTANBUL  
CIZGI Elektronik San. Tic. Ltd. Sti.  
Tel: +90 212 3567070  
Address: CEMAL SURURI CD. HALIM MERIC IS MERKEZI  
No: 15/C D:5-6 34394 MECIDIYEKÖY/ISTANBUL  
EEE Yönetmeliğine Uygundur.

